


Biffi ALGA - EAC

Double-Acting Pneumatic Actuator



This page intentionally left blank.

Table of Contents

Section 1: General Warnings

1.1	Generalities.....	1
1.1.1	Applicable Regulation.....	1
1.1.2	Terms and Conditions.....	2
1.2	Identification Plate.....	2
1.3	Introducing the Actuator.....	2
1.4	Data Sheet.....	3

Section 2: Installation

2.1	Checks Upon Actuator Receipt.....	4
2.2	Actuator Handling.....	4
2.3	Storage.....	7
2.4	Actuator Assembly on the Valve.....	7
2.4.1	Types of Assembly.....	7
2.4.2	Assembly Procedure.....	12
2.5	Pneumatic Connections.....	13
2.6	Electrical Connections (If Any).....	14
2.7	Commissioning.....	15

Section 3: Operation and Use

3.1	Operation Description.....	16
3.2	Residual Risks.....	22
3.3	Calibration of the Angular Stroke.....	22
3.4	Calibration of Microswitches (If Foreseen).....	28
3.5	Calibration of the Operation Time (Optional - If Foreseen).....	29

Section 4: Operational Tests and Inspections

	Operational Tests and Inspections.....	31
--	--	----

Section 5: Maintenance

5.1	Periodic Maintenance.....	32
5.1.1	Check and Restore Oil Level in the Hydraulic Manual Override.....	33
5.1.2	Gas Supply Dehydrating Filter Maintenance (If Foreseen).....	35
5.2	Extraordinary Maintenance	36
5.2.1	Replacement of Cylinder Seals	36
5.3	MHP Hydraulic Manual Override Maintenance and Troubleshooting.....	45
5.3.1	Operation.....	45
5.3.2	Manual Operation.....	45
5.3.3	Remote Operation	45
5.3.4	Setting	46
5.4	Lubrication of Mechanism	48
5.5	Dismantling and Demolition	49

Section 6: Troubleshooting

6.1	Failure or Breakdown Research.....	50
-----	------------------------------------	----

Section 7: Layouts

7.1	Spare Parts Order	51
7.2	Parts List for Maintenance and Replacing Procedure	52

Section 8: Date Report for Maintenance Operations

	Date Report for Maintenance Operations	60
--	--	----

NOTICE

Biffi Italia s.r.l. pays the highest attention to collecting and verifying the documentation contained in this user manual. However Biffi Italia s.r.l. is not liable for any mistakes contained in this manual, for damage or accidents due to the use of the latter. The information contained is of exclusive reserved ownership of Biffi Italia s.r.l. and may be modified without prior notice. All rights reserved.

Section 1: General Warnings

NOTICE

The manual is an integral part of the machine, it should be carefully read before carrying out any operation and it should be kept for future references.

1.1 Generalities

Biffi Italia s.r.l. actuators are conceived, manufactured and controlled according to the Quality Control System in compliance with EN-ISO 9001 international regulation.

1.1.1 Applicable Regulation

EN ISO 12100:2010:	Safety of machinery – General principles for design – Risk assessment and risk reduction
2006/42/EC:	Machine directive
2014/68/EU:	Directive for pressure PED equipment
2014/35/EU:	Directive for low voltage equipment
2014/30/EU:	Directive for the electromagnetic compatibility
2014/34/EU:	Directive and safety instructions for use in hazardous area
TR TS 004/2011	Customs Union Technical Regulation (For safety of low voltage equipment)
TR TS 010/2011	Customs Union Technical Regulation (For safety of equipment and machines)
TR TS 012/2011	Customs Union Technical Regulation (For safety of equipment operated in explosive atmosphere)
TR TS 020/2011	Customs Union Technical Regulation (Electromagnetic Compatibility of Technical Products)
TR TS 032/2013	Customs Union Technical Regulation (For safety of Excess Pressure Equipment)

1.1.2 Terms and Conditions

Biffi Italia s.r.l. guarantees that all the items produced are free of defects in workmanship and manufacturing materials and meet relevant current specifications, provided they are installed, used and serviced according to the instructions contained in the present manual. The warranty can last either one year from the date of installation by the initial user of the product, or eighteen months from the date of shipment to the initial user, depending on which event occurs first. All detailed warranty conditions are specified in the documentation forwarded together with the product. This warranty does not cover special products or components not warranted by subcontractors, or materials that were used or installed improperly or were modified or repaired by unauthorized staff. In the event that a fault condition be caused by improper installation, maintenance or use, or by irregular working conditions, the repairs will be charged according to applicable fees.

The warranty and Biffi Italia s.r.l. liability shall lapse in the event that any modification or tampering whatsoever be performed on the actuator.

1.2 Identification Plate

It is forbidden to modify the information and the marks without previous written authorization by Biffi Italia s.r.l.

The plate fastened on the actuator contains the following information (Figure 1).

Figure 1. Data Plate

		EAC Certificate of Conformity	
Order _____			
ACTUATOR Model _____			
S/N _____		MM/YYYY	
ACTAG N° _____		ND _____	
Supply Press.Range _____		MOP _____	
Amb.Temp. _____		CE _____	
CYLINDER FI.Type _____		FI.Group _____ PED Cat. _____	
TS _____		Test Date _____	
PS _____		PT _____ Cyl.Weight _____	
Ex		Ref.: _____	
		WARNING: Potential Electrostatic Charging Hazard See instructions	


1.3 Introducing the Actuator

The ALGA actuators was engineered and is manufactured to provide maximum torque output with minimum supply pressure. Alga actuators are suitable for the operation of any quarter turn operation such of ball, plug, butterfly valves or dampers, in both ON-OFF and Modulating heavy duty service.

The actuator (see Figure 2) is made up of a weatherproof scotch yoke mechanism transforming the linear movement of the pneumatic cylinder (on closing or opening) into the rotary movement, which is necessary for operation. The angular stroke of the yoke is adjustable between 82° and 98° by means of the external mechanical stops screwed into the left wall of the mechanism housing and into the end flange of the pneumatic cylinder. The cover of the scotch yoke mechanism is arranged for the assembly of the required accessories (positioner, signalling limit switches, position transducer, etc.) by means of proper matching units. The above mentioned accessories are operated by the actuator drive sleeve. The housing of the scotch yoke mechanism has a flange with threaded holes to fix the actuator to the valve either directly or, if required, with the interposition of an adaptor flange or a mounting bracket. The actuator yoke has a hole with keyways suitable for the assembly of an insert bush the internal hole of which is machined (by Biffi or at Customer’s care), according to the shape and dimensions of the valve stem. Biffi can supply different types of control system following Customer’s requirements.

The expected lifetime of actuator is approximately 25 years.

Figure 2. Identification of Actuator Parts



1.4 Data Sheet

Supply fluid	Air, nitrogen or sweet gas, special version available for sour gas
Operating temperature	Standard: from -30 to +100 °C Optional: from -60 to +200 °C
Supply pressure	Please refer to technical document: “actuator data sheet”
Output torque	Up to 750000 Nm (higher value with special version)

Section 2: Installation

2.1 Checks Upon Actuator Receipt

- Check that the model, the serial number of the actuator and the technical data reported on the identification plate correspond with those of order confirmation (Section 1.2).
- Check that the actuator is equipped with the fittings as provided for by order confirmation.
- Check that the actuator was not damaged during transportation: if necessary renovate the painting according to the specification reported on the order confirmation.
- If the actuator is received already assembled with the valve, its settings have already been made at the factory.
- If the actuator is delivered separately from the valve, it is necessary to check, and, if required, to adjust, the settings of the mechanical stops (Section 3.4) and of microswitches (if any) (Section 3.5).

2.2 Actuator Handling

NOTICE

The lifting and handling should be made by qualified staff and in compliance with the laws and provisions in force.

⚠ WARNING


The fastening points are appropriate for the lifting of the actuator alone and not for the valve + actuator assembly. Avoid that during the handling, the actuator passes above the staff. The actuator should be handled with appropriate lifting means. The weight of the actuator is reported on the delivery bill.

For lifting and moving the actuator, use only hooks fitted with safety latch, like the one, for example, shown in Figure 3.

Figure 3. Example of Hook with Safety Latch




Figure 4. Lifting points for ALGA/ALGA-MHP/ALGA-MSJ actuators



1, 2 = Lifting points (obligatory)
 3 = Balancing point

Figure 5. Lifting points for ALGA/ALGA-MHP/ALGA-MSJ actuators





1 = Point of support
 2 = Supports for lateral positioning
 3 = Do not lay the actuator on tie-rods of cylinder/s and do not lay the actuator on accessories (manual handpump, manual jackscrew, pneumatic control group etc.)

- For lifting unbalanced loads, use ropes of different lengths or chains with adjustable length.
- Check each time the conditions of all lifting equipment used and discard it if not in perfect working order.
- Do not knot or twist the ropes so as not to reduce the lifting capacity or produce torsional effects on the load being lifted.
- Use the utmost caution and remain at a safe distance from lifted actuator unless absolutely necessary; do not stand or pass under suspended loads.
- Pay attention in putting under tension the ropes to prevent the load shifting sideways in an uncontrolled manner.
- Use slings of such length that the angles of the leg from vertical are as narrow as possible ($\alpha_{MAX} < 20^\circ$).
- During handling, do not transport the suspended actuator above staff members in charge of the operation.

⚠ WARNING

Do not use the lifting eyelets on actuator to lift valve + actuator assembly.

Figure 6.



⚠ WARNING

Any lifting method different from what described above is strictly forbidden. Biffi reject any responsibility for damages to goods or injuries to persons coming from wrong lifting operations.

2.3 Storage

If the actuator needs storage, before installation follow these steps:

- Place it on a wood surface in order not to deteriorate the area of valve coupling.
- Make sure that plastic plugs are present on the pneumatic and electrical connections (if present).
- Check that the cover of the control group and of the limit switch box (if any) are properly closed.

If the storage is long-term or outdoor:

- Keep the actuator protected from direct weather conditions.
- Replace plastic plugs of pneumatic and electrical connections (if any) with metal plugs that guarantee perfect tightness.
- Coat with oil, grease or protection disc, the valve coupling area.
- Periodically operate the actuator (Section 3.3).

2.4 Actuator Assembly on the Valve

2.4.1 Types of Assembly

For coupling to the valve, the housing is provided with a flange with threaded holes according to Biffi standard tables (SCN6200; SCN6200-1; SCN6201; SCN6201-1). The number, dimensions and diameter of the holes are made in accordance with ISO 5211, but for actuator models 0.3 to 6 the holes are drilled on the centerline in order to allow an easier assembly of an intermediate flange, when required. This intermediate flange (or spool-piece) can be supplied when the valve flange can not directly match the actuator flange in its “standard” configuration. For the biggest actuator models, the actuator flange can be machined in accordance with the valve flange dimensions.

The yoke has bored with keyways for coupling to the valve stem, the dimensions of which are according to Biffi standard tables SCN6200 and SCN6201:

Figure 7.




Table 1. Dimensions (mm)

Actuator model	$\varnothing d_1$	$\varnothing d_2$	$\varnothing d_3$	$\varnothing d_4$	N	h_1	h_2	H max	$\varnothing d_5$	W	K
0.3	240	93	165	M20	4	5	17	127	70	12	75.6
0.9	310	112	254	M16	8	5	19	150	86	14	93.6
1.5	360	144	298	M20	8	6	19	190	112	18	119.0
3	430	195	365	M30	8	9	23	200	157	25	167.8
6	520	250	406	M36	8	14	29	260	200	28	212.8

Figure 8.




Table 2. Dimensions (mm)

Actuator model	$\varnothing d_1$	$\varnothing d_2$	$\varnothing d_3$	$\varnothing d_4$	N	h_1	h_2	H max	$\varnothing d_5$	W	K
14	580	250	483	M36	12	10	29	340	175	45	195.8
18	680	290	603	M36	16	12	32	350	200	45	220.8
32	780	310	603	M36	16	12	32	400	220	50	242.8
35	780	315	603	M36	16	12	32	400	240	56	264.8
42	840	310	603	M36	16	12	32	400	220	50	242.8

Figure 9.




Table 3. Dimensions (mm)

Actuator model	$\varnothing d_1$	$\varnothing d_2$	$\varnothing d_3$	$\varnothing d_4$	N	h_1	h_2	H max	$\varnothing d_5$	W	K
50	800	315	698	M36	24	10	32	430	240	56	264.8
60	840	315	698	M36	24	10	32	430	240	56	264.8

If required, for the standard models size 0.3 to 6, Biffi can supply an insert bush with un-machined bore in accordance with Biffi standard table SCN6202. On request the insert bush bore can be machined by Biffi to couple the valve stem, provided its dimensions match the maximum stem acceptance of the bush according to Biffi doc.: TN1005. The particular execution of the flange and bushing allow the actuator to be rotated by 90° in 4 different positions according to the Figure 10.

Figure 10. Insert bush + intermediate coupling flange




Table 4.

Position 2	Position 3	Position 4
Rotate insert-bush 180° around vertical-standard position (1)	Rotate insert-bush 180° around axis A-A, from position 2	Rotate insert-bush 180° around axis A-A from position 1
Insert bush turned upside down		

The Biffi insert bush with 2 external keys at 45° allows to position the keyway for the valve every 90°. Consequently, actuator can be mounted in 4 positions at 90° on top of the valve. For biggest actuator models, the bore of the yoke can be machined according to the dimensions of valve stem.

2.4.2 Assembly Procedure

NOTICE

Failure to comply with the following procedures may impair product warranty.

WARNING

Installation, commissioning and maintenance and repair works should be carried out by qualified staff. A non-conforming assembly could be the source of serious accidents.

For actuator assembly on the valve:

NOTICE

If necessary to mount components not in Biffi scope of supply please check the accessories mounting hole details in the documents TN 1028 (for metric dimension) or TN 1028U (for imperial dimension).

NOTICE

Check that the assembly position, as shown on the documentation, complies with system's geometry. Check the consistency of the parts of actuator-valve coupling.

- Operate the actuator so that it reaches the position matching valve position (Section 3.3).
- Lubricate valve stem with oil or grease.
- Properly clean and remove grease from coupling flange surfaces.
- Connect, if supplied separately, the adjustment insert to valve stem and fasten it with the special fastening pins.
- Lift the actuator using the special lifting points (Section 2.2).
- Install the actuator so that valve stem inserts in the coupling area. This coupling should be made without forcing.
- Fasten the two parts with the threaded connections (screws, tie rods, nuts). If holes of coupling flanges are not aligned, adequately operate the actuator if necessary move the mechanical stops backwards (Section 3.4).
- Fasten threaded connections. Please refer to Table 5.

Table 5. Nuts Tightening Torque

Threading	Tightening torque (Nm)
M8	20
M10	40
M12	70
M14	110
M16	160
M20	320
M22	420
M24	550
M27	800
M30	1100
M33	1400
M36	1700

The screwing values in Table 5 were calculated considering the materials ASTM A320 L7 for screws or tie rods and ASTM A194 gr.2H for the nuts.

2.5 Pneumatic Connections

⚠ WARNING

Check that the values of pneumatic supply available are compatible with those reported on the identification plate of the actuator.

NOTICE

The connections should be made by qualified staff. Use pipes and connections appropriate as for type, material and dimensions.

- Properly de-burr the ends of rigid pipes.
- Properly clean the interior of pipes sending through them plenty of the supply fluid used in the system.
- Mould and fasten the connection pipes so that no irregular strains at entries or loosening of threaded connections occur.
- Make the connections according to the operating diagram.
- Check the absence of leakages from pneumatic connections.

2.6 Electrical Connections (If Any)

NOTICE

Use components appropriate as for type, material and dimensions.

⚠ WARNING

The connections should be made by qualified staff.
Before carrying out any operation, cut line power off.

Safety provisions:

2006/95/EC: Directive for low voltage equipment (until 19 April 2016) 2014/35/EU from 20 April 2016


2004/108/EC: Directive for the electromagnetic compatibility (until 19 April 2016) 2014/30/EU from 20 April 2016

94/9/CE: Directive and safety instructions for use in hazardous Area (until 19 April 2016) 2014/34/EU from 20 April 2016

Remove plastic plugs from cables entries

- Screw firmly the cable glands.
- Introduce connection cables.
- Make the connections in compliance with applicable wiring diagrams on the documentation supplied.
- Screw the cable gland.
- Replace the plastic plugs of unused entries with metal plugs.

Figure 11. Junction box on Control group (if foreseen)



2.7 Commissioning

Check that values of electrical supply to the control group (if foreseen) are compatible with those on the plate on the junction box (Figure 11).

WARNING

Installation, commissioning and maintenance and repair works should be made by qualified staff.

Upon actuator commissioning please carry out the following checks:

- Check that paint is not be damaged during transport, if necessary repair the damages to paint coat.
- Check that the pressure and quality of the gas supply (filtering degree, dehydration) are as prescribed. Check that the feed voltage values of the electric components (solenoid valve coils, microswitches, pressure switches, etc.) are compatible with those reported on the identification plate of the actuator (Figure 1).
- Check that the setting of the components of the actuator control unit (pressure regulator, pressure switches, flow control valves, etc.) meet the plant requirements.
- Carry out all kinds of operations and check their proper execution (Section 3.3).
- Check the absence of leakages in the pneumatic connections. If necessary tighten the nuts of the pipe-fittings.
- Check proper operation of all the due signalling (valve position, gas supply pressure etc.).
- Make a complete functional test in order to verify all the operations are executed according to operating schematic diagram supplied.

Section 3: Operation and Use

3.1 Operation Description

In the normal operating situation, the ALGA actuator is fed by pressurized gas which flows into the relevant cylinder chamber (for example opening). The cylinder piston stroke causes the actuator operation and the consequent valve movement to the operational position requested (in this case to the “open” position).

Upon a demand, the closing chamber the cylinder is fed by pressurized gas and at the same time the gas is discharged from the open chamber into the return line: the actuator performs the closing operation driven by the piston movement, and the valve moves from the open position to the close (safety-related) position.

Figure 12.




Figure 13.





Table 6. Parts list

Item	Name
1	Housing
2	Yoke
3	Yoke bushing
4	Cover
5	Guide block pin
6	Sliding block
7	Guide block
8	Guide bar
9	Guide block bushing
10	Travel stop screw
11	Cylinder head flange
12	Piston rod bushing
13	Piston rod seal ring
14	Piston rod
15	Piston
16	Piston guide sliding ring
17	Piston seal ring
18	Cylinder tube
19	End flange
20	Travel stop screw
21	Sealing washer
22	Tie rod

For local or remote operations, please refer for information only to Section 3.1 to Section 3.4 and prior to technical documentation furnished with actuators.


Typical schematics for various applications are as follows for information only, the function described are furnished only on specific customer demand. For all the relevant information, please refer to the specific technical documentation supplied with actuators.

Figure 14. ON-OFF service: four way control valve




The diagram shows the simplest ON-OFF control. The gas supply pressure is applied to one side of the cylinder and exhausted from the opposite side. When the control valve (2) is actuated the connection of supply and exhaust to the cylinder chambers are reversed. The control valve can have many types of actuating devices (solenoid, manual control, pneumatic pilot, spring, etc.). The spring-return control valves allow “fail-safe” operation.

Figure 15. ON-OFF service: air fail-safe system




The system allows “fail-safe” operation when the pressure in the gas supply line drops below a set value. The diagram shows the actuator in the “fail-safe” condition. When the gas supply pressure drops below the pressure switch (5) set point, the pneumatic supply to the solenoid valve (6) pilot is exhausted and the actuator moves to the “fail-safe” position by using the gas stored in the tank (4). The tank is connected to the gas supply through the check valve (3).


Figure 16. Modulating service



When modulating control is required as a function of a pneumatic or electric control signal, a positioner (5) is used, which controls the supply to the actuator cylinder to keep the valve in the required angular position. The positioner has a mechanical linkage to the actuator, for a feedback of the valve position.


Figure 17. Emergency manual override

For models up to three, the MHW-MSJ jackscrew manual override can be provided. The jackscrew end of the override is screwed into the guide block and it is installed on the actuator's left side. A bronze split screw nut is mounted inside the body. The manual operator has a declutch system, the screw nut is engaged with the jackscrew by turning the engagement lever. The body of the screw container is rotated manually by rotating a lever (for MSJ models) or a handwheel (for MHW models) once the screw nut is engaged with the jackscrew. Refer to the actuator's label shown in Figure 21.

Figure 18. MHP hydraulic manual override

The MHP hydraulic manual override is used to manually operate the actuator in lack of air supply. It also allows to accurately adjust the actuator operating times, independently in opening and in closing, by way of the hydraulic regulators which work on the oil flow from one chamber to the other of the hydraulic cylinder during pneumatic operation. Moreover, it permits a smooth angular speed all along the stroke. During manual operation the flow regulators are by-passed to make the force on the handpump lever easy. The MHP unit consists of a hydraulic cylinder mounted directly on the actuator. The piston rod end is screwed into the guide block. The compact hydraulic control unit consists of a handpump, directional control valve, oil tank, relief valve and two unidirectional flow regulators. The directional control valve has three operating positions: "remote": the actuator is operated by pneumatic supply; "to open": the actuator operation is opening by handpump. On request, the hydraulic manual override type MHP2 (double handpump version) can be supplied which allows the remote control to automatically override manual operation.

Figure 19.



- | | |
|--|--|
| <ul style="list-style-type: none"> 1 - SCOTCH YOKE MECHANISM 2 - PNEUMATIC CYLINDER 3 - HYDRAULIC CYLINDER 4 - HYDRAULIC MANUAL OVERRIDE █ - HIGH PRESSURE OIL █ - INTERMEDIATE PRESSURE OIL █ - LOW PRESSURE OIL █ - PRESSURIZED AIR █ - ATMOSPHERIC PRESSURE AIR | <ul style="list-style-type: none"> RA = RELIEF VALVE FOR AUTOMATIC OPERATION RM = RELIEF VALVE FOR MANUAL OPERATION P = HANDPUMP D = HAND OPERATED DIRECTIONAL CONTROL VALVE FA = UNIDIRECTIONAL FLOW REGULATOR (OPENING OPERATION) FC = UNIDIRECTIONAL FLOW REGULATOR (CLOSING OPERATION) FR = BIDIRECTIONAL FLOW REGULATOR CV = CHECK VALVE OT = OIL TANK LS = LEVEL STICK WITH RELIEF VALVE |
|--|--|

3.2 Residual Risks


⚠ WARNING

It is recommended to pipe exhaust gas.
The actuator has parts under pressure.
Use the due caution. Use individual protections provided for by the laws and provisions in force.

3.3 Calibration of the Angular Stroke

The angular stroke of the yoke can be adjusted between 82° to 98° ($\pm 4^\circ$ with respect to the nominal positions of complete opening and closing) by means the mechanical stops screwed into the left side of the housing (open valve) and into the end flange of the pneumatic cylinder (closing), see Figure 20.

Figure 20. Mechanical stops



In case of an actuator with two cylinders (Figure 21), both mechanical stops are screwed on the end flanges of the cylinders.

Figure 21. Actuator with two cylinders



For the adjustment of the travel stop screws, proceed as follows: (see Figures 22 and 23).

1. Loosen the lock nut (2) with a proper wrench (C2).
2. If the actuator angular stroke is stopped before reaching the end position (fully open or closed), unscrew the stop screw (1) by turning it anticlockwise with a proper wrench (C1), until the valve reaches the right position. When unscrewing the stop screw, keep the lock nut still with a wrench so that the sealing washer (3) does not withdraw together with the screw.
3. If the actuator angular stroke is stopped beyond the end position (fully open or closed valve), screw the stop screw by turning it clockwise until the valve reaches the right position.
4. Tighten the lock nut (2).

Figure 22.




Table 7.

Pneumatic cylinder size	Wrench C1 (mm)	Wrench C2 (mm)
85	30	41
100	30	41
135	30	30
175	30	30
235	30	30

Figure 23.




Table 8.

Pneumatic cylinder size	Wrench C1 (mm)	Wrench C2 (mm)
280	17	55
335	17	55
385	17	55
435	17	55
485	17	55
535	17	55
585	17	55
635	17	55
735	17	55
785	17	55
835	17	55
885	17	55
935	17	55
1000	17	55
1100	17	55
1200	17	55
1300	17	80
1450	17	80

For the adjustment of the mechanical stop screwed into the left side of housing, follow these steps (Figure 22 and 24):

- Loosen the locknut (D) with the specific wrench (C2).
- Adjust the pin (G)/screw (V) with the adequate wrench (C1).
- Turn counterclockwise to increase the angular stroke, turn clockwise to decrease it.
- When the adjustment is over tighten the locknut (D).

Figure 24. Mechanical stop on the housing




Table 9.

Actuator model	Wrench C1 (mm)	Wrench C2 (mm)
0.3	30	30
0.9	30	30
1.5	41	41
3	41	41
6	46	46

Figure 25. Mechanical stop on the housing





Table 10.

Actuator model	Wrench C1 (mm)	Wrench C2 (mm)
14	17	60
18	17	60
32	17	60
50	17	60

Figure 26. Optional (if foreseen)



For the adjustment of the mechanical stop screwed on the end flange of manual override (see Section 7.2 Table 26: sectional drawing for manual jackscrew MSJ – MHW).

Figure 27. Mechanical stop on the end flange of manual override




Table 11.

GIG actuator model	Wrench C1 (mm)	Wrench C2 (mm)
0.3	34	34
0.9	34	34

Figure 28. Mechanical stop on the end flange of manual override





Table 12.

GIG actuator model	Wrench C1 (mm)	Wrench C2 (mm)
1.5	24	65
3	24	65

Figure 29. Optional (if foreseen)



For the adjustment of the mechanical stop on the end flange of hydraulic cylinder of MHP, follow these steps (Figure 30):

- Remove with the specific wrench (C1) the plug (T).
- Insert a wrench for Allen keys (C2) in the through hole until reaching the adjustment pin (G).
- Keep the protection cover blocked with the special wrench (C3).
- Turn counterclockwise to increase the angular stroke, turn clockwise to decrease it.
- When the adjustment is over tighten the plug (T).

Figure 30. Mechanical stop of the MHP cylinder




Table 13.

Hydraulic cylinder size	Wrench C1 (mm)	Wrench C2 (mm)	Wrench C3 (mm)
075	22	10	36
100	22	10	36
135	22	10	36
175	22	14	46
200	27	14	46
235	27	17	65
280	27	17	65
300	36	17	110

3.4 Calibration of Microswitches (If Foreseen)

(Refer to Safety Instructions Manual for limit switch box)

⚠ WARNING

Refer only to technical documentation related to installed switch box model.

NOTICE

For mounting interface dimension of the Limit Switch box on the cover of the actuator, please refer to TN1163V (for metric dimension) or TN1163VU (for imperial dimension).


NOTICE

Operate only the microswitch corresponding to the direction of operation being carried out, as clearly reported on the microswitch. End of stroke microswitches should be operated before the stop of the stroke of the actuator due to mechanical stops. Adjust the relative cams properly.

3.5 Calibration of the Operation Time (Optional - If Foreseen)

The calibration of the operation time is made by Biffi Italia s.r.l. according to customer requirements and to technical data-sheet included in technical documentation. If necessary it's possible to modify or reset the operating time through two flow regulation valves placed between the control valves enclosure and the pneumatic cylinder (Figure 31).

Figure 31. Example of operating-time adjustment (if foreseen)



To carry out the adjustment, use an adequate Allen wrench and follow these steps (Figure 3):


- Loosen the locknut.
- Screw with a screwdriver the setting screw to increase the operation time.
- Unscrew with a screwdriver the setting screw to decrease the operation time.
- After the adjustment is over screw the locknut.

For ALGA actuator models with Manual Handpump, the operating time is adjustable through two regulation valves placed on manual handpump body (see Section 7.2 Table 24: sectional drawing for hydraulic control unit MHP).

To carry out the adjustment, use a suitable Allen wrench and follow these steps (Figure 32):

- Remove the cap nut.
- Loosen the locknut.
- Screw with a screwdriver the setting screw to increase the operation time.
- Unscrew with a screwdriver the setting screw to decrease the operation time.
- After the adjustment is over screw the locknut and put back in place the cap nut.

Figure 32. Flow regulators placed on manual handpump (optional - if foreseen)



Section 4: Operational Tests and Inspections

NOTICE

To ensure the guaranteed SIL grade, according to IEC 61508, the functionality of actuator must be checked with regular intervals of time, as described in the Safety Manual.

Section 5: Maintenance

NOTICE

Before executing any maintenance operation, it is necessary to close the pneumatic supply line and discharge pressure from the cylinder of the actuator and from the control unit (if foreseen).

⚠ WARNING

Installation, commissioning and maintenance and repair works should be carried out by qualified staff.

5.1 Periodic Maintenance

ALGA actuators are designed to operate long-term in heavy-duty operating conditions, without maintenance needs.

NOTICE

Periodicity and regularity of inspections is particularly influenced by specific environmental and working conditions. They can be initially determined experimentally and then be improved according to actual maintenance conditions and needs.

Anyway every 2 years of operation the following is recommended:

- Check that the actuator operates the valve correctly and with the required operating times. If the actuator operation is very infrequent, carry out a few opening and closing operations with all the existing controls (remote control, local control, emergency controls, etc.), if this is allowed by the conditions of the plant (refer to specific operating diagram in technical documentation furnished with actuators).
- Check there are no hydraulic or pneumatic leakages.
- Check oil level (Figure 33) into the hydraulic control unit (see Section 5.1.1).
- Check the actuators did not undergo accidental damage with oil leakages found on site (Section 5.1.1).
- Check that improper closing of control-group cover did not produce the presence of condensation on it.
- Check the integrity of worn out parts (gaskets, pads, etc.).
- Replace, if any, the mechanical filter of the supply gas (refer to Section 5.1.2).


Figure 33. Level measuring stick



5.1.1 Check and Restore Oil Level in the Hydraulic Manual Override

Operate the distributor lever to “closing manual operation”.

Figure 34.



Move the actuator into its “fail to close” position. Unscrew the dipstick (1).

Check that the oil level into the tank (4) is in correspondence of the “MAX LEVEL” notch of the dipstick. Screw and tighten the dipstick.

If necessary, substitute or add the oil, proceeding as follow:

- Remove the dipstick (1) from the tank cover (22).
- Unscrew the plug (27) and the washer (9) to drain all the oil.
- If some dirt or/and sludge is found in the oil drained from the tank, before filling with new oil in the tank, disassemble the oil tank tube, by unscrewing the two cap nuts (2), and clean the internal surfaces of the tank. If necessary substitute the gaskets (21) of the tank.
- Replace the plug (27) and the washer (9) into the plate (11) and tighten.
- Pour the new oil into the tank through the dipstick hole (1) on the cover (22).
- Replace the dipstick (1).
- Add oil (refer to Table 14) if in the tank the oil level is BELOW THE MINIMUM (Figure 33: minimum level is in correspondence to the end of dipstick) until to reach the optimal (MAXIMUM) oil level.
- Operate the distributor lever to “Remote” position.

NOTICE

For refill use oil of the same brand as previous, refer to related technical documentation.

Table 14. Features of hydraulic oil suggested by Biffi Italia s.r.l. for refilling in different working condition:

Standard temperature conditions (-30 °C/+85 °C)	
Producer	AGIP
Name	ARNICA 22
Viscosity at 40 °C	20.9 mm ² /s
Viscosity at 100 °C	4.73 mm ² /s
Viscosity index ASTM	153
Flash point	192 °C
Pour point	-42 °C
Specific weight (at 15 °C)	0.857 kg/l
Equivalent oils	SHELL TELLUS PLUS 22 CHEVRON HYDRAULIC OIL AW ISO 22 MOBIL DTE22 EXXON UNIVIS N22 EQUIVIS ZS22 BP ENERGOL HLP-HM22 CASTROL DYSPIN AWS22
Low temperature conditions (down to -46 °C)	
Manufacturer	SHELL
Name	AEROSHELL FLUID 41
Viscosity at -54 °C	2300 cST
Viscosity at -40 °C	491 cST
Viscosity at 40 °C	14.1 cST
Viscosity at 100 °C	5.3 cST
Viscosity index (ISO 2909)	>200
Flash point	105 °C
Pour point	<-60 °C
Specific weight	0.87 kg/dm ³
(Or equivalent)	
Low temperature conditions (down to -60 °C)	
Manufacturer	SYNTHESIS
Name	SYNTRASS-CS 500
Viscosity at -60 °C	580 cST
Viscosity at -30 °C	39cST
Viscosity at 20 °C	5.8 cST
Viscosity at 50 °C	2.1 cST
Flash point	152 °C
Pour point	-68 °C
Specific weight	0.897 kg/dm ³
(Or equivalent)	

5.1.2 Gas Supply Dehydrating Filter Maintenance (If Foreseen)

The gas supply filter is fitted with a mechanical filter and a drain valve to discharge periodically the water generated by the condensation of the humidity inside the gas supply.


During the routine maintenance, it is recommended to check and clean the mechanical filter, and replace it in case of heavy dirty conditions.

To disassemble the filter, proceed as follow:

- A. Close the stop valve at the inlet of pressure supply line;
- B. Discharge the pressure from the drain valve;
- C. Remove the lower enclosure screws;
- D. Remove the mechanical filter;
- E. Clean or replace the filter;

Reinstall all parts carefully paying attention to avoid any damage to the O-ring.

Figure 35.



5.2 Extraordinary Maintenance

If there are leaks in the hydraulic cylinder, pneumatic cylinder or a malfunction in the mechanical components, or in case of scheduled preventive maintenance, the actuator must be disassembled and seals must be replaced with reference to the follow general sectional drawing and adopting the following procedures.

5.2.1 Replacement of Cylinder Seals

(Refer to Figure 36)

WARNING

Before executing any maintenance operation, it is necessary to intercept the supply line and discharge pressure from the cylinder of the actuator.

NOTICE

If the actuator can be operated, it is essential to take it to fail-safe position, otherwise the actuator should be disassembled from the valve and follow these steps:

1. Remove the nuts (16) and the washers (24) from the tie rods (18) at the end flange (22) side.
2. Slide off the end flange (22) and the tube (19).
3. Remove the screw (2) and the cover (1).
4. Unscrew the piston rod (20) threaded end from the adaptor bush (30) of guide block (14).
5. Slide off the piston rod (20) from the head flange (17).
6. Disassemble the head flange (17) from the mechanism housing (8) by removing the screw (15) only if the gasket (36) has to be replaced because damaged.

Seals replacement

Prior to reassemble check that the actuator components are in good conditions and clean. Lubricate all the surfaces of the parts, which move in contact with other components, by recommended oil (SHELL OMALA® S4 WE or equivalent). If the O-ring must be replaced, remove the existing one from its groove, clean the groove carefully and lubricate it with protective oil film. Assemble the new O-ring into its groove and lubricate it with a protective oil film.

1. Replace the O-rings (39-40) of the head flange (17).
2. Replace the O-ring (42) and the guide sliding ring (41) of the piston (21).
Replace the O-ring (40) of the end flange (22).

If the sealing washer (43) has to be replaced, measure the protrusion of the stop screw (26) with reference to the end flange (22) surface, so as to be able to easily restore the setting of the actuator mechanical stop in the closed valve position, once the maintenance procedures have been completed.

1. Loosen the lock nut (25) and unscrew the stop screw (26) until it is removed together with the nut (25), the washer (44) and the sealing washer (43).
2. Remove the sealing washer (43) from the stop screw (26). Carefully clean and lubricate the stop screw thread and the surface of the end flange area, on which the sealing washer works.
3. Screw the new sealing onto the stop screw until it touches the nut (25).
4. Assemble the washer (44) onto the sealing washer (43).
5. Screw the stop screw into the threaded hole of the end flange until it reaches its original position (the same protrusion with reference to the flange surface).
6. Check that the sealing washer (43) and the washer (44) are in contact with the flange surface.
7. Tighten the lock nut (25).

Reassemble

1. Assemble the new gasket (36) after cleaning the surfaces of housing (8) and head flange (17), which are in contact.
2. Assemble the head flange (17), replace the washers (37) if damaged, tighten the screws (15) to the recommended torque.
3. Lubricate the piston rod (20) surface, with a protective oil film and introduce it into the head flange hole, taking care not to damage the O-ring (39). Carefully clean the threaded end of the piston rod (20) and the threaded hole of the adaptor bush (30) of guide block (14). Spreads some sealant LOCTITE® 452, or equivalent, on the rod threaded end and screw into the adaptor bush (30) threaded hole and tighten.
4. Carefully clean the inside of the tube (19) and check that the entire surface, particularly that of the bevels, is not damaged. Lubricate the inside surface of the tube and the bevels at the ends. Slide the tube onto the piston taking care not to damage the piston O-ring (42) and the head flange O-ring (40).
5. Assemble the end flange by centring it on the inside diameter of the tube, taking care not to damage the O-ring (40).
6. Assemble the washers (24) and the nuts (16) onto the tie rods (18). Tighten the nuts to the recommended torque, alternating between opposite corners.
7. Restore a generous coating of grease on the contact surfaces of the yoke (11) and the bushing (33), on the yoke grooves, on the sliding block (5), on guide bar (9).
8. Assemble the new gasket (10) after cleaning the surfaces of the housing (8) and cover (1).
9. Lubricate with protective oil the O-ring (32).
10. Assemble the cover (1) and the screw (2). Tighten the screws to the recommended torque.
11. Carry out a few actuator operations to check that its movement is regular and that there is no air leakage through the seals.

NOTICE

After maintenance operations carry out a few actuator operations (5 to 10) to check that its movement is regular, that there is no air leakage through the seals and to eliminate any oil residues in the air circuit, deriving from the lubrication of the seals during the replacement phase.

Figure 36. ALGA double-acting pneumatic actuator




Table 15. Parts list

Item	Name
1	Cover
2	Screw
3	Guide block pin
4	Vent valve
5	Sliding block
6	Screw
7	Screw
8	Housing
9	Guide bar
10	Cover gasket
11	Yoke
12	Plug
13	Bushing
14	Guide block
15	Screw

Item	Name
16	Nut
17	Head flange
18	Tie rod
19	Cylinder tube
20	Piston rod
21	Piston
22	End flange
23	Lifting eyelet
24	Spring washer
25	Nut
26	Stop setting screw
27	Nut
28	Nut
29	Stopper bush
30	Adaptor bush
31	Washer
32	O-ring
33	Yoke bushing
34	Retainer ring
35	Flange
36	Gasket
37	Washer
38	Piston rod bushing
39	O-ring
40	O-ring
41	Guide sliding ring for piston
42	O-ring
43	Sealing washer
44	Washer

Replacement of hydraulic cylinder seals (see Figure 40) only for ALGA-MHP hydraulic handpump manual override

If there are leaks in the hydraulic cylinder or a malfunction in the mechanical components, or in case of scheduled preventive maintenance, the actuator must be disassembled and seals must be replaced with reference to the sectional drawing and adopting the following procedures:

1. Remove the nuts (item 16) and the washers (item 15) from the tie rods (item 10) at the end flange (item 13) side.
2. Slide off the end flange and the tube (item 12).
3. Remove the screws (item 2 - Figure 36) and the cover (item 1 - Figure 36).
4. Unscrew the piston rod (item 6) threaded end from the adaptor bush (item 30 - Figure 36) of guide block (item 14 - Figure 36).
5. Slide off the piston rod from the head flange (item 2).
6. Disassemble the head flange from the mechanism housing (item 8 - Figure 36) by removing the screws (item 7 - Figure 36) only if the gasket (item 36 - Figure 36) has to be replaced because damaged.

Seals replacement

Prior to reassemble check that the actuator components are in good conditions and clean. Lubricate all the surfaces of the parts, which move in contact with other components, by recommended oil (SHELL OMALA S4 WE or equivalent). If the O-ring must be replaced, remove the existing one from its groove, clean the groove carefully and lubricate it with protective oil film. Assemble the new O-ring into its groove and lubricate it with a protective oil film.

1. Replace the O-rings (3) of the head flange (2).
2. Replace the O-ring (3) of the end flange (13).

For replacement of piston rod seal ring (4) and of the O-ring (5) proceed as follows:

1. Remove the existing Teflon seal ring (4) and the O-ring (5) from their groove.
2. Clean the groove carefully and lubricate it with a protective oil film.
3. Assemble the new O-ring into its groove and lubricate it with a protective oil film.
4. Assemble the new Teflon seal ring (4) into the flange groove, on the rubber O-ring (5), by bending it: take care that the bending radius is as large as possible to avoid damaged the seal. Then enlarge the seal ring with your fingers so as to restore its round shape: pay attention not to utilize any tools, which can damage the seal ring.

To replace the piston seal ring (9) and the O-ring (19) proceed as follows:

1. Remove the existing Teflon seal ring (9) and the O-ring (19) from their groove.
2. Clean the groove carefully and lubricate it with a protective oil film.
3. Assemble the new O-ring into its groove and lubricate it with a protective oil film.
4. Assemble the new Teflon seal ring (9) on its rubber O-ring (19) by introducing one side of it into the groove and then enlarge it with your fingers so as to introduce it into the groove: take care to enlarge it uniformly without any tools which could possibly damage it. The elastic memory of the kind of Teflon type the seal ring is made of allows the ring to shrink back to its previous dimension after a short time.

If the O-ring (17) has to be replaced, measure the protrusion of the stop screw (11) with reference to the end flange (13) surface, so as to be able to easily restore the setting of the actuator mechanical stop in the open valve position, once the maintenance procedures have been completed.

5. Loosen the stop setting screw cover (14) and unscrew the stop screw (11).
6. Remove the O-ring (17) from the stop screw (11). Carefully clean and lubricate the stop screw thread and the surface of the end flange area, on which the O-ring works.
7. Screw the new O-ring onto the stop screw until it touches the cover (14).
8. Screw the stop screw into the threaded hole of the end flange until it reaches its original position (the same protrusion with reference to the flange surface).
9. Check that the O-ring (17) is inside the groove into the end flange and in contact with the groove bottom surface.

Reassemble

1. Assemble the new gasket (item 36 - Figure 36) after cleaning the surfaces of housing (item 8 - Figure 36) and head flange (item 2) which are in contact.
2. Assemble the head flange and tighten the screws (item 7 - Figure 36) to the recommended torque.
3. Clean and lubricate the piston rod (item 6) surface, particularly that of the bevel, with a protective oil or grease film and introduce it into the head flange hole, taking care not to damage the Teflon seal ring (item 4): the piston rod bevel has to enlarge smoothly the seal ring.
4. Carefully clean the threaded end of the piston rod and the threaded hole of the adaptor bush (item 30 - Figure 36) of guide block (item 14 - Figure 36). Spread some sealant LOCTITE 452, or equivalent, on the rod threaded end and screw into the adaptor bush threaded hole and tighten.

5. Carefully clean the inside of the tube (item 12) and check that the entire surface, particularly that of the bevels, is not damaged. Lubricate with protective oil film the tube inside surface and the bevels at the ends. Slide the tube onto the piston taking care not to damage the Teflon seal ring (item 9): the tube bevel has to smoothly compress the seal ring.
6. Take care also not to damage the head flange O-ring (item 3).
7. Assemble the end flange (item 13) by centring it on the inside diameter of the tube, taking care not to damage the O-ring (item 3).
8. Assemble the washers (item 15) and the nuts (item 16) onto the tie rods (item 10). Tighten the nuts to the recommended torque, alternating between opposite corners.
9. Restore a generous coating of grease on the contact surfaces of the yoke (item 11 - Figure 36) and the bushings (item 13 - Figure 36), on the yoke grooves, on the sliding blocks (item 5 - Figure 36), on guide bar (item 9 - Figure 36).
10. Assemble the new gasket (item 36 - Figure 36) after cleaning the surfaces of the housing (item 8 - Figure 36) and cover (item 1 - Figure 36)
11. Lubricate with protective oil the O-ring (item 32 - Figure 36).
12. Assemble the cover (item 1 - Figure 36) and the screws (item 2 - Figure 36). Tighten the screws to the recommended torque.

NOTICE

After maintenance operations carry out a few actuator operations (5 to 10) to check that its movement is regular, that there is no air leakage through the seals and to eliminate any oil residues in the air circuit, deriving from the lubrication of the seals during the replacement phase.

Figure 37. Hydraulic cylinder




Table 16. Parts list

Item	Name
1	Piston rod bushing
2	Head flange
3	O-ring
4	Piston rod seal ring
5	O-ring
6	Piston rod
7	Piston
8	Guide sliding ring for piston
9	Piston seal ring
10	Tie rod
11	Stop setting screw
12	Cylinder tube
13	End flange
14	Stop setting screw cover
15	Spring washer
16	Nut
17	O-ring
18	Plug
19	O-ring
20	Plug

5.3 MHP Hydraulic Manual Override Maintenance and Troubleshooting

5.3.1 Operation

(see the attached operating diagram MAN 562-A)

The “MHP” hydraulic manual override and speed control unit is utilized, in connection with the actuator hydraulic cylinder, for the manual operation and for the speed control during the pneumatic operation of pneumatic double-acting actuators.

5.3.2 Manual Operation

Selected by the hand operated directional control valve (D) the operation (opening or closing) to be performed.

Actuate the handpump (P).

The relief valve (Rm) prevents that the oil pressure delivered by the handpump exceeds the set value so to not damage the valve or the actuator.

5.3.3 Remote Operation

To allow the actuator pneumatic operation the hand operated directional control valve (D) has to be in its “REMOTE” control position: valve lever in its central position as shown by the instructions plate.

Pneumatic operation

The oil flows from the hydraulic cylinder chamber, rear flange side, via the flow regulator (Fa), the valve (D) and the flow regulator (Fc), free flow direction, to the hydraulic cylinder chamber, head flange side.

The exceeding oil volume, corresponding to the hydraulic cylinder piston rod, flows via the flow regulator (Fr) into the oil tank (Ot).

The relief valve (Ra) prevents that the oil pressure, into the hydraulic cylinder, exceeds a set value.

The flow regulator (Fa) allows the setting of the actuator operation speed in opening independently from the actuator speed in closing.

Pneumatic closing operation

The oil flows from the hydraulic cylinder chamber, head flange side, via the flow regulator (Fc), the valve (D) and the flow regulator (Fa), free flow direction, to the hydraulic cylinder chamber, rear flange side.

The missing oil volume, corresponding to the piston rod of hydraulic cylinder, is sucked from the oil tank via the check valve (Cv).

The flow regulator (Fc) allows the setting of the actuator operation speed in closing, independently from the actuator speed in opening.

5.3.4 Setting

A) Setting of the actuator operating times (see the attached sectional drawings)

The setting of actuators operating times in opening and in closing is performed by adjusting the unidirectional flow regulators (items Fa and Fc of operating diagram MAN 562-A) assembled into the plate (item 11): into the plate left side the flow regulator for the actuator opening time setting; into the plate right side the flow regulator for the actuator closing time setting.

As the flow regulators are unidirectional type the actuator operating times can be set independently in opening and in closing.

To perform the setting of the flow regulators proceed as follows:

- Unscrew the cap nut (item 2) from the setting screw (item 28).
- Loosen the lock nut (item 30).
- By a screwdriver rotate clockwise the setting screw (item 28) to increase the operating time; rotate counter clockwise to decrease the operating time.
- Check that the operating time is the required one.
- Tighten the lock nut (item 30). During this operation keep the setting screw (item 28) still with a screwdriver.
- Screw the cap nut (item 2) on the setting screw end and tighten so to assure the tightness.

B) Settings of relief valves (see the attached sectional drawings)

The relief valve (item Ra of operating diagram MAN562-A) is set at Biffi factory at a proper value and there is no reason to change the setting on the field.

The relief valve (item Ra of operating diagram MAN562-A) is set at Biffi factory at a pressure value at least 20% higher than the pressure required into the hydraulic cylinder, during the manual operation by the handpump, to overcome the valve required torque, in opening and in closing, along all the valve angular stroke.

At the same time the set value is at least 10% lower than the pressure required into the hydraulic cylinder to perform the maximum allowable torque of the actuator and of the valve.

If a setting of the relief valve has to be performed, proceed as follows:

- Unscrew the cap nut (item 2) from the setting screw (item 44).
- Loosen the lock nut (item 30).
- By a male hexagonal wrench rotate clockwise the setting screw (item 44) to increase the pressure setting value; rotate counterclockwise to decrease the pressure set value.
- Check that the pressure set value is the required one.
- Tighten the lock nut (item 30). During this operation keep the setting screw (item 44) still with an hexagonal male wrench.
- Screw the cap nut (item 2) on the setting screw end and tighten so to assure the tightness.

Figure 38. Hydraulic cylinder




Table 17. Parts list

Item	Qty	Description	Material
1	1	Dipstick	Carbon steel + Aluminium
2	5	Cap nut	Carbon steel
3	8	Washer	Carbon steel + rubber
4	1	Hydraulic tank	Carbon steel
5	1	Handpump	See attached table
6	2	O-ring	* Fluorosilicone rubber
7	2	Ball	Stainless steel
8	2	Spring	Spring steel
9	2	Washer	Carbon steel + rubber
10	1	Screw	Carbon steel
11	1	Plate	Carbon steel
12	1	Flange	Aluminium
13	8	Screw	Carbon steel
14	1	Lever	Carbon steel
15	1	Distributor	Stainless steel
16	1	O-ring	* Fluorosilicone rubber
17	1	O-ring	* Fluorosilicone rubber
18	1	Nozzle	Carbon steel
19	2	Screw	Carbon steel
20	3	O-ring	* Fluorosilicone rubber

NOTE:
* Recommended spare parts

Item	Qty	Description	Material
21	1	Tank gasket	* Fiber
22	1	Tank cover	Carbon steel
23	2	Tie rod	Carbon steel
24	1	Screw	Carbon steel
25	1	Flange	Aluminium
26	2	Check valve body	Carbon steel
27	1	Plug	Carbon steel
28	2	Flow control valve setting screw	Stainless steel
29	2	Spring pin	Stainless steel
30	3	Nut	Carbon steel
31	2	Flange	Carbon steel
32	2	O-ring	* Fluorosilicone rubber
33	2	Spring	Spring steel
34	2	Plug	Stainless steel
35	2	Retainer ring	Spring steel
36	2	Spring pin	Carbon steel
37	2	Rivet	Aluminium
38	1	Operation instruction plate	Stainless steel
39	4	Screw	Carbon steel
40	1	Spring	Stainless steel
41	3	Ball	Stainless steel
42	2	Ball	Stainless steel
43	1	Spring	Spring steel
44	1	Relief valve setting screw	Stainless steel
45	3	Spring pin	Carbon steel
46	1	Screw	Alloy steel
47	1	Spring	Stainless steel
48	1	Tank gasket	* Polyurethane

NOTE:

* Recommended spare parts

5.4 Lubrication of Mechanism

For normal duty the scotch yoke mechanism of the actuator is lubricated “for life”. In case of high load and high frequency of operation it may be necessary to periodically restore lubrication: it is advisable to apply a generous coating of grease on the contact surfaces of the yoke and bushings, on the yoke link grooves, on the sliding blocks, on the guide bar.

For this operation it is necessary to disassemble the mechanism cover. In larger actuators the lubrication can be performed through the inspection holes of the cover after removing the plugs.

The following grease is used by BIFFI for standard working temperature and suggested for re-lubrication:

Table 18.

AGIP MU/EP/2		AEROSHELL GREASE 7 or equivalent	
To be used in standard temperature conditions:	(-30 °C/+85 °C)	To be used in low temperature conditions:	(-60 °C/+65 °C)
NLGI consistency:	2	Color:	Buff
Worked penetration:	280 dmm	Physical state:	Semi-solid at ambient temperature
ASTM Dropping Point:	185 °C	Odour:	Slight
Base oil viscosity at 40 °C:	160 mm ² /s	Density:	966 kg/m ³ at 15 °C
ISO Classification:	L-X-BCHB 2	Flash Point:	>215 °C (COC) (Based on synthetic oil)
DIN 51 825:	KP2K - 20	Dropping point:	260 °C (ASTM D-566)
Equivalent to:	ESSO BEACON EP2 BP GREASE LTX2 SHELL ALVANIA GREASE R2 ARAL ARALUB HL2 CHEVRON DURALITH GREASE EP2 CHEVRON SPHEEROL AP2 TEXACO MULTIFAK EP2 MOBILPLEX 47 PETROMIN GREASE EP2	Product code:	001A0065
		Infosafe No.:	ACISO GB/eng/C

5.5 Dismantling and Demolition

Before starting the disassembly a large area should be created around the actuator so to allow any kind of movement without problems of further risks created by work site.

WARNING

Before disassembling the actuator it is necessary to close the pneumatic feed line and discharge pressure from the cylinder of the actuator, from the control unit and from the accumulator tank, if present.

If actuator is still mounted onto the valve, loosen the threaded connections between valve and actuator (screws, tie rods, nuts).

Lift the actuator using the proper lifting points (see Section 2.2 to Section 3.5).

If the actuator needs storage, before demolition, see Section 2.2.

The demolition of the actuator both concerning any electrical and mechanical parts should be made by specialized staff.

Separate the parts composing the actuator according to their nature (ex. metallic and plastic materials, fluids, etc.) and send them to differentiated waste collection sites, as provided for by the laws and provisions in force.

Section 6: Troubleshooting

6.1 Failure or Breakdown Research

Table 19.

Event	Possible cause	Remedy
Actuator does not work	Lack of power supply	Restore it
	Lack of pneumatic supply	Open line interception valve
	Blocked valve	Repair or replace
	Wrong position of the distributor of the manual hydraulic group	Restore correct position
	Failure of the control group	Call Biffi Italia s.r.l. Customer Service
Actuator too slow	Low supply pressure	Restore (Section 1.4)
	Wrong calibration of flow regulator valves	Restore (Section 3.6)
	Wear of the valve	Replace
Actuator too fast	High supply pressure	Restore (Section 1.4)
	Wrong calibration of flow regulator valves	Restore (Section 3.6)
Leakages on hydraulic or pneumatic circuits	Deterioration and/or damage to gaskets	Call Biffi Italia s.r.l. Customer Service
Incorrect position of the valve	Wrong adjustment of mechanical stops	Restore (Section 3.4)
	Wrong warning of microswitches	Restore (Section 3.5)
Hydraulic manual pump does not work	Handle positioned on remote control	Position the handle on the indication of the operation to make
	Leakages on the check valve of the hydraulic control group	Call Biffi Italia s.r.l. Customer Service

Section 7: Layouts

7.1 Spare Parts Order

For spare parts order to the relevant Biffi office please make reference to Biffi order confirmation concerning all the supply, and serial number of the actuator (Section 1.2) for any specific spare part for a specific actuator model.

Please send every spare parts request to :

Biffi Italia s.r.l. - Spares Office

Tel.: +39 0523-944523

Fax: +39 0523-941885

E-mail: Biffispares@Emerson.com

Please specify :

1. Actuator model
2. Biffi acknowledgement
3. Spare parts code
4. Quantity
5. Transport condition
6. Involved people

7.2 Parts List for Maintenance and Replacing Procedure

Figure 39. Scotch yoke mechanism




Table 20. Parts list

Item	Qty	Description	Material
1	4	O-ring	* Fluorosilicone rubber
2	2	Yoke bushing	Bronze
3	2	Retainer ring	Stainless steel
4	1	Housing	Carbon steel
5	1	Guide bar	Alloy steel
6	1	Yoke	Carbon steel
7	1	Cover gasket	* SBR + Cellulose + Fillers
8	1	Guide block	Carbon steel
9	1	Bushing	Steel + Bronze + PTFE
10	2	Sliding block	Bronze
11	1	Vent valve	* Stainless steel
12	12	Screw	Carbon steel
13	1	Cover	Carbon steel
14	1	Guide block pin	Alloy steel

NOTE:

* Recommended spare parts

Figure 40. Pneumatic cylinder




Table 21. Parts list

Item	Qty	Description	Material
1	1	Piston rod bushing	Steel + Bronze + PTFE
2	1	O-ring	* Fluorosilicone rubber
3	2	Gasket	* NBR 870260
4	1	Head flange	Carbon steel P355NL1 UNI EN 10028-1
5	8	Nut	Carbon steel ASTM A194 gr. 7
6	4	Tie rod	Alloy steel ASTM A320 gr. L7
7	1	Cylinder tube	Carbon steel ASTM A333 gr. 6
8	1	Piston rod	Alloy steel
9	1	Piston	Carbon steel ASTM A350/A350M gr. LF2 Class 1
10	1	End flange	Carbon steel ASTM A350/A350M gr. LF2 Class 1
11	2	Lifting eyelet	Carbon steel
14	1	Sealing washer	* ELVAX 450
15	1	Nut	Carbon steel (SUR-SULF®)
16	1	Stop setting screw	Carbon steel (SUR-SULF)
17	1	Guide sliding ring for piston	* PTFE + Graphite
18	1	O-ring	* Fluorosilicone rubber

NOTE:

* Recommended spare parts

Figure 41. Hydraulic cylinder (optional: only for ALGA-MHP hydraulic handwheel manual override)




Table 22. Parts list

Item	Qty	Description	Material
1	1	Piston rod bushing	Steel + Bronze + PTFE
2	1	Head flange	Carbon steel
3	2	O-ring	* NBR rubber
4	1	Piston rod seal ring	* Teflon + Graphite
5	1	O-ring	* NBR rubber
6	1	Piston rod	Alloy steel
7	1	Piston	Nickel plated carbon steel
8	2	Guide sliding ring for piston	* PTFE + graphite
9	1	Piston seal ring	* PTFE + NBR rubber
10	4	Tie rod	Alloy steel ASTM A320 gr. L7
11	1	Stop setting screw	Alloy steel
12	1	Cylinder tube	Nickel plated carbon steel
13	1	End flange	Carbon steel
14	1	Stop setting screw cover	Carbon steel
15	4	Spring washer	Carbon steel
16	4	Nut	Carbon steel ASTM A194 gr. 7
17	1	O-ring	* NBR rubber
18	6	Plug	Carbon steel
19	1	Plug	Carbon steel
20	1	Plug	Carbon steel

NOTE:

* Recommended spare parts

Figure 42. Assembly kit




Table 23. Parts list

Item	Qty	Description	Material
1	1	Screw	Alloy steel
2	1	Nut	Carbon steel
3	1	Nut	Carbon steel
4	4	Screw	Alloy steel
5	1	Flange	Carbon steel
6	2	Gasket	* SBR + Cellulose + Fillers
7	1	Stopper bush	Alloy steel
8	1	Plug	Stainless steel
9	1	Adaptor bush	Alloy steel
10	4	Screw	Alloy steel
11	4	Washer	Copper
12	1	Washer	Alloy steel

NOTE:

* Recommended spare parts

Figure 43. Hydraulic control unit MHP





Table 24. Parts list

Item	Qty.	Description	Material	Item	Qty.	Description	Material
1	1	Dipstick	-	32	2	O-ring	*Fluorosilicone rubber
2	2	Cap nut	Carbon steel	33	2	Spring	Spring steel
3	2	Washer	Carbon steel + Rubber	34	2	Plug	Stainless steel
4	1	Hydraulic tank	Carbon steel	35	2	Retainer ring	Spring steel
5	1	Handpump	See attached table	36	2	Spring pin	Carbon steel
6	2	O-ring	*Fluorosilicone rubber	37	4	Screw	Carbon steel
7	2	Ball	Stainless steel	38	1	Operation instruction plate	Stainless steel
8	2	Spring	Spring steel	39	4	Screw	Carbon steel
9	1	Washer	Carbon steel + Rubber	40	1	Spring	Stainless steel
10	1	Screw	Carbon steel	41	1	Ball	Stainless steel
11	1	Plate	Carbon steel	42	4	Ball	Stainless steel
12	1	Flange	Aluminium	43	2	Spring	Spring steel
13	4	Screw	Carbon steel	44	1	Relief valve setting screw	Stainless steel
14	1	Lever	Carbon steel	45	2	Spring pin	Carbon steel
15	1	Distributor	Stainless steel	46	1	Screw	Alloy steel
16	1	O-ring	*Fluorosilicone rubber	47	1	Spring	Stainless steel
17	1	O-ring	*Fluorosilicone rubber	48	1	Nut	Carbon steel
18	1	Nozzle	Carbon steel	49	1	Washer	Carbon steel + Rubber
19	2	Screw	Carbon steel	50	2	Washer	Carbon steel + Rubber
20	3	O-ring	*Fluorosilicone rubber	51	1	Dipstick	Stainless steel
21	2	O-ring	*Fluorosilicone rubber	52	1	Plug + O-ring	*
22	1	Tank cover	Carbon steel	53	1	Spring	Stainless steel
23	2	Tie rod	Carbon steel	54	1	Screw	Alloy steel
24	1	Screw	Carbon steel	55	1	Nut	Carbon steel
25	1	Flange	Aluminium	56	1	Silencer	Brass
26	2	Check valve body	Aluminium	57	2	O-ring	*Fluorosilicone rubber
27	2	Plug	Carbon steel	58	2	Retainer ring	Spring steel
28	2	Flow control valve setting screw	Stainless steel	59	1	Dipstick body	Aluminium
29	2	Spring pin	Stainless steel	60	2	Nut	Carbon steel
30	2	Nut	Carbon steel	61	1	Relief valve body	Aluminium
31	2	Flange	Carbon steel				

NOTE:

* Recommended spare parts

Figure 44. Handpump**Table 25. Parts list**

Item	Qty	Description	Material
1	2	Ball	Stainless steel
2	1	Delivery valve bush	Carbon steel
3	1	Suction valve bush	Carbon steel
4	2	Spring	Stainless steel
5	1	Suction valve ring	Carbon steel
6	1	Spring retainer ring	Carbon steel
7	1	Fork	Carbon steel
8	2	Pin	Stainless steel
9	4	Retainer ring	Carbon steel
10	1	Rod	Alloy steel
11	1	Body	Carbon steel
12	1	Lever	Carbon steel
13	1	Split pin with rope	Nylon + Carbon steel
14	1	Scraper ring	* PTFE + fluorosilicone rubber
15	1	Threaded bush	Aluminium
16	2	Rod seal ring	* PTFE + Graphite
17	2	O-ring	* Fluorosilicone rubber
18	1	O-ring	* Fluorosilicone rubber
19	1	Nut	Carbon steel
20	1	Screw	Carbon steel
21	1	Fork	Carbon steel
22	1	Piston rod bushing	Steel + Bronze + PTFE

NOTE:

* Recommended spare parts

Figure 45. Jackscrew manual override MSJ or MHW




Table 26. Parts list

Item	Qty	Description	Material
1	1	Protection pipe	Carbon steel
3	1	Jackscrew	Carbon steel
4	1	Engagement lever pin	Stainless steel
5	1	O-ring	* Fluorosilicon rubber
6	1	Cover gasket	* Fiber
7	1	Cover	Carbon steel
8	3	Cam	Alloy steel
9	1	Fork	Carbon steel
10	3	Spring pin	Stainless steel
11	3	Screw	Carbon steel
12	1	Screw nut operating cam	Alloy steel
13	1	O-ring	* Fluorosilicon rubber
14	1	Thrust nut operating cam	Alloy steel
15	1	Screw	Carbon steel
16	1	Nut	Carbon steel
17	1	Flange	Carbon steel
18	1	Body	Carbon steel
19	1	Spring pin	Spring steel
20	2	Screw	Carbon steel
21	1	Ball 1/4"	Stainless steel
22	1	Screw	Carbon steel
23	1	Screw nut	Bronze
24	1	Pin	Carbon steel
25	1	Spring	Spring steel
26	1	Bush	Bronze
27	2	Thrust shoulder washer	Bronze
28	1	Operating instruction plate	Aluminium

NOTE:

* Recommended spare parts

Section 8: Date Report for Maintenance Operations

Last maintenance operation date:

(in factory, on delivery):

..... exec. by :

..... exec. by :

..... exec. by :

Next maintenance operation date:

..... exec. by :

..... exec. by :

..... exec. by :

Start-up date:

..... (in factory, on delivery)

..... (on plant)

This page intentionally left blank.

Biffi Italia s.r.l.
Strada Biffi 165
29017 Fiorenzuola d'Arda (PC)
Italy
T +39 0523 944 411

For complete list of sales and manufacturing sites, please visit
www.biffi.it or contact us at biffi_italia@biffi.it

VCIOM-15305-EN © 2023 Biffi. All rights reserved.

The contents of this publication are presented for information purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the designs or specifications of our products at any time without notice.

