

Biffi IMVS2000v2

Biffi Assistant User Manual



Revision Details

Rev.	Date	Description	Prepared	Approved
3	March 2021	General update (Migration to new template)		
2	October 2017	Third issue	L. Piacenti	A. Battaglia
1	December 2016	Second Issue	L. Piacenti	A. Battaglia
0	December 2014	First Issue	A. Battaglia	M.A. Comelli

Table of Contents

Section 1: Reference Documents

Reference Documents.....	1
--------------------------	---

Section 2: Introduction

Introduction	2
--------------------	---

Section 3: Communication Interface Selection and Login

3.1 Interface Selection and Settings	4
3.2 Login and Connections.....	6
3.2.1 RS232 Connection	6
3.2.2 Bluetooth Connection	10
3.3 User Levels (Login)	19

Section 4: Biffi Assistant Functions

4.1 Navigate Through the Biffi Assistant Menus.....	21
4.1.1 Main Menu Name.....	21
4.1.2 Minimize/Maximize Menus	22
4.1.3 Biffi Assistant's Structure.....	25
4.2 Read/Update Parameters	26
4.2.1 Read/Update a Single Parameter	26
4.2.2 Read/Update all the Parameters of a Single Sub-Menu (Tab).....	28
4.2.3 Read/Update all the Parameters of Single Menu (Block).....	31
4.2.4 Read/Update all the Parameters of the Device.....	33
4.2.5 Read Measures Menu.....	35
4.3 Write Parameters	37
4.3.1 Write a Single Parameter	37
4.3.2 Write all the Parameters of a Single Sub-Menu (Tab).....	40
4.3.3 Write all the Parameters of a Single Menu (Block)	43
4.2.4 Write all the Parameters of the Device.....	46
4.4 Launch/Send a Command	49
4.5 Change Password	50
4.5.1 Change "Online" Password	50
4.5.2 Change "Offline" Password.....	50

Section 5: Import/Export Files

5.1	Import File	51
5.1.1	Import File - Online.....	52
5.1.2	Import File - Offline	54
5.2	Export File.....	58
5.2.1	Export File - Online	58
5.2.2	Export File - Offline.....	62

Section 6: List of Parameters

6.1	View Graph of the Biffi Assistant Menu	64
-----	--	----

Section 7: Graphs

7.1	General View - Graphs	70
7.1.1	General View - FST Graphs	70
7.1.2	General View - PST Graphs.....	71
7.2	Grid View - Graphs	72
7.3	Chart View	77
7.3.1	Chart View - Full Screen	83
7.3.2	Chart View - Export Graph	85
7.3.3	Chart View - Select X Axis and Reverse X Axis.....	86
7.4	Stored Graphs	88

Appendix A: RS232 Cable

Appendix A:	RS232 Cable	90
-------------	-------------------	----

Appendix B: Approved Bluetooth Adapters List

Appendix B:	Approved Bluetooth Adapters List.....	91
-------------	---------------------------------------	----

Appendix C: Biffi Assistant PC Requirements

Appendix C:	Biffi Assistant PC Requirements	92
-------------	---------------------------------------	----

Appendix D: Biffi Assistant Install/Uninstall

D.1	Install Biffi Assistant	93
D.2	Uninstall Biffi Assistant.....	95

Section 1: Reference Documents

[1]: IMVS2000v2 Installation and Operation Manual, Biffi document MAN720.

WARNING

For any information regarding actuator parameters or settings please refer to the relevant IMVS2000v2 and Actuator documentation. Wrong parameter settings may cause actuator malfunctions.

WARNING

All parameters changes not saved into the internal application database or sent to the actuator will be lost once the application is closed.

WARNING

It is assumed that the installation, setting, commissioning, maintenance and repair works are carried out by qualified personnel and checked by responsible Specialists. Operating the actuator and the IMVS2000v2 could damage the actuator and cause personal injury.

WARNING

Any repair work other than the operations outlined in this manual will be strictly reserved to qualified Biffi Italia personnel or to personnel directly authorized by the Company itself.

WARNING


Whenever the PC will be used in HAZARDOUS AREA as defined by the applicable rules, it is mandatory to check whether the PC nameplates indicate their suitability to a hazardous area, and the appropriate protection degree.

Section 2: Introduction

The Biffi Assistant software tool is a software application for the PC that creates a versatile tool for configuring and maintaining multiple IMVS2000v2 devices.

The Biffi Assistant provides the ability to configure, diagnose and collect data for IMVS2000v2 devices on the PC / Windows platform (see Appendix C).

Figure 1 Data Plate



Section 3: Communication Interface Selection and Login

Users may connect directly to an IMVS2000v2 device by using Biffi Assistant through Bluetooth and RS232.

A direct connection with Biffi Assistant is convenient for users that need to configure or diagnose many IMVS2000v2 devices or users who require immediate detailed analysis on a large screen on-site. Note that Biffi Assistant may save "transfer files" to review at a later time.

WARNING

It is recommended to use only one Serial Communication Interface (RS232 or Bluetooth) per time to avoid configuration errors.


NOTICE

When Biffi Assistant connection (RS232 or Bluetooth) is active, the IMVS2000v2 automatically inhibits the using of the Local Operator Interface and the display shows the sentence "Biffi Assistant Connected".

3.1 Interface Selection and Settings


When the Biffi Assistant starts, the following screen appears.
Left-Left-click of the mouse on “Options”, for setting the Communication Interface.

Figure 2



Select the Communication Interface/Channel Type (RS232 or Bluetooth).
On the right corner of “Options” it is indicated the SW version of Biffi Assistant.

Figure 3



According to the selected “Channel Type”, set the parameters as follows (*):

Table 1.

	RS232	Bluetooth
COM port	set the used COM uconnection	-
Baud Rate (bps)	115200 (fixed)	115200 (fixed)
Channel Timeout (ms)	6000	6000
Read timeout, dynamic length (ms)	100000	100000
COM parity	0 (fixed)	0 (fixed)
COM databits	8 (fixed)	8 (fixed)
COM stopbits	1 (fixed)	1 (fixed)
Bluetooth connection timeout (ms)	-	6000
Language	en (fixed)	en (fixed)

Left-click of the mouse on “Save” for applying the setting otherwise left-click of the mouse on “Undo”.

The selected Interface, with its settings, will be used by the Biffi Assistant, for the connection with the device.

Before starting the connection, verify that the selected interface is enabled (see [1]).

For restoring the default settings, left click of the mouse on “Restore default settings”.

(*) it is indicated the typical value of the parameters. In some cases (PC with low performance) it could be necessary to increase the value of the following parameters: “Channel Timeout”, “Read timeout, dynamic length” and “Bluetooth connection timeout”.

3.2 Login and Connection

See 3.1 to select the Communication Interface and to set it correctly.


3.2.1 RS232 Connection

It is supposed that the cable connection is correctly made.

For the RS232 connection see Appendix A: RS232 Cable and [1].


Left-click of the mouse on “Work Online”, for starting the connection with the IMVS2000v2.

Figure 4




The “preliminary” connection starts.

Figure 5




Wait for the end of the “preliminary” connection until the Login screen queries the user for a “User” and a “Password”.

Figure 6




To login, select the “User” (see 3.3 for details), insert the password and left-click of the mouse on “Login” (or press ENTER). To cancel the Login, left-click of the mouse on the left arrow.

Figure 7




If the password is correct the connection with the IMVS2000v2 starts.

Figure 8



When the IMVS2000v2 is connected (“User” = USER) the following screen appears.

Figure 9




For Logging out, left-click of the mouse on “Logout User Level”.

3.2.2 Bluetooth Connection

For the Bluetooth, to operate properly, bring the PC to within 10 meters of the IMVS2000v2 device. Note that Bluetooth configuration is provided by your Bluetooth hardware manufacturer (see Appendix B for the approved USB/Bluetooth adapters).


1. Left-click of the mouse on “Work Online“, for starting the connection with the IMVS2000v2.

Figure 10




2. Left click of the mouse on “Start”, for searching the Bluetooth devices.

Figure 11



3. Double Left-click of the mouse on the desired device, for starting the connection. If the password is correct, the connection with the IMVS2000v2 starts.

Figure 12




At this point, depending on the Bluetooth stack of the laptop and on the Bluetooth module installed into the device, the following three different connection sequences can occur:

- Direct connection to the Device Password page (Section 3.2.2.1)
- Notice of the Bluetooth Connection before Device Password page (Section 3.2.2.2)
- Request of Bluetooth password before Device Password page (Section 3.2.2.3)

3.2.2.1 Direct Connection to the Device Password Page

The “Preliminary” Connection Starts.

Figure 13




Go to step 4.

3.2.2.2 Notice of the Bluetooth Connection Before Device Password Page


Left click of the mouse on the message that appear in the bottom on the right.

Figure 14




Left click of the mouse on the “Next” button.

Figure 12



Left click of the mouse on the “Close” button.

Figure 16




Go to step 4.

3.2.2.3 Request of Bluetooth Password Before Device Password Page



Left click of the mouse on the message that appear in the bottom on the right.

Figure 17




Insert the password “0000” and then click on the “Next” button.

Figure 18



Left click of the mouse on the “Close” button.


Figure 19




Go to step 4.

4. Wait until the end of the “preliminary” connection and the Login screen queries the user for a “User” and a “Password”.


Figure 20



- To login, select the “User” (see 3.3 for details), insert the password and left-click of the mouse on “Login” (or press ENTER). To cancel the Login left-click of the mouse on the left arrow.


Figure 21

- If the password is correct the connection with the IMVS2000v2 starts.

Figure 22

7. When the IMVS2000v2 is connected (“User” = USER) the following screen appears.

Figure 23





For Logging out, left-click of the mouse on “Logout User Level”.

3.3 User Levels (Login)

For logging in with the IMVS2000v2, it is possible to select four different “User”: User (Actuator’s users), VAC (Actuator’s users), FACTORY (Actuator’s users), Observer (Special users) and Guest_S (Special User).

Figure 24



- OBSERVER:** Observer level may not configure or alter device in any way but is allowed to export all the configuration parameters stored on the IMVS2000v2. This authorization level is ideal for technicians with little or no training or authority for changing configurations. This is the lowest level of authorization and does not allow the device configuration to be changed.
- GUEST_S:** Special authorization appropriate for Biffi authorized technician. This level allows a representative of Biffi to modify all the configuration parameters of the IMVS2000v2.
- USER:** User level may configure the device. A subset of parameters is available. User level authority is typically the technician with responsibility for maintaining and updating IMVS2000v2 configuration. It is possible to export the configuration parameters (subset) and the graphs stored on the IMVS2000v2.
- VAC:** Special authorization appropriate for Biffi authorized technician. This level allows a representative of Biffi to modify all the configuration parameters of the IMVS2000v2.
- FACTORY:** Special authorization appropriate for Biffi Factory personnel. This authorization allows the user to use specific utilities and should never be used by the end customer.

Section 4: Biffi Assistant Functions

WARNING

It is recommended to use only one Serial Communication Interface (RS232 or Bluetooth) per time to avoid configuration errors.

NOTICE


The IMVS2000v2 automatically inhibits the using of the Local Operator Interface when one Biffi Assistant connection (RS232 or Bluetooth) is active.

4.1 Navigate through the Biffi Assistant Menus

4.1.1 Main Menu Name

The name of the Main Menu is determined by the “Dev. Tag” parameter (see 6 and [1]). In the screen below it is “IMVS2000v2”.

Figure 25



4.1.2 Minimize/Maximize Menus

For minimizing or maximizing the Menus of the Biffi Assistant there are two possible ways:

- Single left-click of the mouse on the arrow on the left of the Menu Name
- Double left-click of the mouse on the Menu Name

Figure 26









Figure 27



For moving inside a Menu, use the scroll bar.

Figure 28




4.1.3 Biffi Assistant’s Structure

The Biffi Assistant structure is organized as follows:

- MAIN MENU
 - MENU 1
 - ...
 - ...
 - MENU #N
 - Sub-Menu N_1
 - ...
 - ...
 - Sub-Menu N_x
 - Parameter / Command N_x_1
 - ...
 - ...
 - Parameter / Command N_x_y

The MAIN MENU can contain several MENUs (Blocks).
 Each MENU (block) can contain several Sub-Menus (Tabs).
 Each Sub-Menu (Tab) can contain several Parameters / Commands.
 For each parameter are defined: Name, Value, UM (Unit Measure), Min (Minimum value), Max (Maximum value) and the Flags (R, R/W).

Figure 29



See 6 and [1] for details about the parameters.
 See paragraph from 4.2 to 4.5 for reading/writing parameters and launching commands.

4.2 Read/Update Parameters

During the connection process (see 3.2) the value of the parameters is not updated.

The parameters of a single Sub-Menu (Tab) are automatically updated at first access to the Sub-Menu (Tab); for the further accesses, the updating of the parameters must be done manually.

It is possible to manually update all the parameters of a Sub-Menu (Tab) simultaneously (see 4.2.2), to update them individually (see 4.2.1), to update all the parameters of a Menu (Block) (see 4.2.3) or to update all the parameters of the device at the same time (see 4.2.4).

The readable parameters are the ones classified as “RW” or “R” into the “Flags” field that are not commands (see 6).


For reading the value of the parameters of the “Measures” Menu see 4.2.5.

For launching a command see 4.4.

4.2.1 Read/Update a Single Parameter


Right-click of the mouse on the row of the parameter that must be updated and then left-click of the mouse on “Read Object object ID”.

Figure 30




The updating of the parameter starts.

Figure 31



Wait until the updating process stops.

Figure 32




4.2.2 Read/Update All the Parameters of a Single Sub-Menu (Tab)

There are two ways for reading/updating all the parameters of a single tab:


1. Right-click of the mouse on the row of any parameter of the Sub-Menu (Tab) that must be updated and then left-click of the mouse on “Read tab Tab Name”.

Figure 33




- Right-click of the mouse on the name of the Sub-Menu (Tab) that must be updated and then left-click of the mouse on “Read tab Tab Name”.

Figure 34




The updating of the parameter starts.

Figure 35



Wait until the updating process stops.

Figure 36




4.2.3 Read/Update All the Parameters of Single Menu (Block)

There are two ways for reading/updating all the parameters of a single tab:


1. Right-click of the mouse on the name of the Menu (Block) that must be updated and then left-click of the mouse on “Read block Block Name”.

Figure 37




The updating of the parameter starts.

Figure 38



Wait until the updating process stops.


Figure 39



4.2.4 Read/Update All the Parameters of the Device


Right-click of the mouse on the name of the Main Menu then left-click of the mouse on “Read all active objects” and confirm the writing operation (a confirmation window appears).

Figure 40




The updating of the parameter starts.

Figure 41



Wait until the updating process stops.


Figure 42



4.2.5 Read Measures Menu


Open the “Measures” Menu (Block) and select the “Measures” Sub-Menu (Tab).

Figure 43





Left-click of the mouse on the row of the parameter to be read (“Position” in the screen below).

Figure 44



Left-click of the mouse on “Start cyclical reading”, for reading/updating the value of the parameter every two seconds.

Figure 45



Left-click of the mouse on “Stop cyclical reading” for stopping the cyclical reading. The cyclical reading is automatically stopped by selecting another parameter or by exiting from the Sub-Menu (Tab).

4.3 Write Parameters



The Biffi Assistant allows writing all the parameters of a Sub-Menu (Tab) simultaneously (see 4.3.2), writing them individually (see 4.3.1), writing all the parameters of a Menu (Block) (see 4.3.3) or writing all the parameters of the device at the same time (see 4.3.4).

The writable parameters are the ones classified as “RW” into the “Flags” field that are not commands (see 6).

4.3.1 Write a Single Parameter

Select, through the mouse, the “Value” field of the parameter that must be written and type the new value or select the new value from the available list (it depends on the type of parameter).


Figure 46



Right-click of the mouse on the row of the parameter that must be updated and then left-click of the mouse on “Write Object object ID” and confirm the writing operation (a confirmation window appears).


Left-click of the mouse on “Undo object object ID” to cancel the writing operation.

Figure 47




The writing process starts.

Figure 48



Wait until the writing process stops.

Figure 49



4.3.2 Write All the Parameters of a Single Sub-Menu (Tab)

⚠ WARNING


During the connection process (see 3.2) the value of the parameters is not updated.

Before performing the writing of all the parameters of a Sub-Menu (Tab) it is necessary to verify that all the parameters of the Tab have the correct value.

Before performing the writing command, it is suggested to update the value of all the parameters of the Tab (see 4.2.2) or to import a valid file (see 5).

Select, through the mouse, the “Value” field of the parameters that must be written and type the new values or select the new values from the available list (it depends on the type of parameter).


Figure 50



There are two ways for writing all the parameters of a single tab:


1. Right-click of the mouse on the row of any parameter of the Sub-Menu (Tab) that must be written and then left-click of the mouse on “Write tab Tab Name” and confirm the writing operation (a confirmation window appears). Left-click of the mouse on “Undo object Tab Name” to cancel the writing operation.

Figure 51




2. Right-click of the mouse on the name of the Sub-Menu (Tab) that must be written and then left-click of the mouse on “Write tab Tab Name” and confirm the writing operation (a confirmation window appears). Left-click of the mouse on “Undo tab Tab Name” to cancel the writing operation.

Figure 52




The writing of the parameters starts.

Figure 53



Wait until the updating process stops.

Figure 54



4.3.3 Write All the Parameters of a Single Menu (Block)

WARNING


During the connection process (see 3.2) the value of the parameters is not updated.

Before performing the writing of all the parameters of a Menu (Block) it is necessary to verify that all the parameters of the Block have the correct value.

Before performing the writing command, it is suggested to update the value of all the parameters of the Block (see 4.2.3) or to import a valid file (see 5).


Select, through the mouse, the “Value” field of the parameters that must be written and type the new values or select the new values from the available list (it depends on the type of parameter).

Figure 55




Right-click of the mouse on the name of the Menu (Block) that must be updated and then left-click of the mouse on “Write block Block Name” and confirm the writing operation (a confirmation window appears). Left-click of the mouse on “Undo block Block Name” to cancel the writing operation.

Figure 56




The writing of the parameters starts.

Figure 57



Wait until the writing process stops.

Figure 58




4.3.4 Write All the Parameters of the Device

WARNING

During the connection process (see 3.2) the value of the parameters is not updated. Before performing the writing of all the parameters of the Device it is necessary to verify that all the parameters of the Device have the correct value. Before performing the writing command, it is suggested to update the value of the parameters (see 4.2.4) or to import a valid file (see 5).


Select, through the mouse, the “Value” field of the parameters that must be written and type the new values or select the new values from the available list (it depends on the type of parameter).

Figure 59




Right-click of the mouse on the name of the Main Menu then left-click of the mouse on “Write all active objects” and confirm the writing operation (a confirmation window appears). Left-click of the mouse on “Undo all objects” to cancel the writing operation.

Figure 60




The writing of the parameters starts.

Figure 61



Wait until the writing process stops.


Figure 62



4.4 Launch/Send a Command


The commands are classified as “RW” into the “Flags” field (see 6 for the full list of commands). Right-click of the mouse on the row of the command that must be sent and then left-click of the mouse on “Send command Command ID”.

Figure 63




The command is performed.

Figure 64



Wait until the command is completed and left-click of the mouse on the “OK” button of the Information Window that appears.

Figure 65



4.5 Change Password

4.5.1 Change “Online” Password

The IMVS2000v2 has four levels of Password for working online (see 3.3); the only one that can be changed by the User is the “User” password.

The IMVS2000v2 does not allow changing the “User” password through the Biffi Assistant; it is necessary to use the Local Operator Interface (see [1]) for performing this operation.

4.5.2 Change “Offline” Password

See 5.1.2.1.

Section 5: Import/Export File

WARNING

It is recommended to use only one Serial Communication Interface (RS232 or Bluetooth) per time to avoid configuration errors.

NOTICE

The IMVS2000v2 automatically inhibits the using of the Local Operator Interface when one Biffi Assistant connection (RS232 or Bluetooth) is active.

The Biffi Assistant provides the possibility to import and export the configuration files (parameters) and to export the stored graph of the IMVS2000v2.

It is also possible to work off-line to analyse/modify the exported files.

The Biffi Assistant allows exporting the files in two different ways:

- Biffi Assistant file (.Biffia)
- Text file (.txt)

The Biffi Assistant allows importing only the Biffi Assistant files (.Biffia).

5.1 Import File

The Biffi Assistant allows importing a configuration file in two ways:

- Online (see 5.1.1)
- Offline (see 5.1.2)


5.1.1 Import File – Online

The importation of a configuration file through Biffi Assistant is normally used for changing some or all the parameters of the device that is connected (Online).


For importing a file Online the following steps must be performed:

1. Establish a connection with the device (see 3).
2. Left-click of the mouse on “Import”.


Figure 66



3. A “Windows Explorer” window is automatically opened. Browse for finding the file to import. Select the file to import and left click of the mouse on “Open”.

Figure 67

4. Wait until the file is imported.

Figure 68

Now it is possible to download to the device the data imported by using one of the available writing procedures (see 4.3).


5.1.2 Import File – Offline

The Offline importation of Biffi Assistant file is normally used to analyse/modify the exported files.

For importing a file Offline the following steps must be performed:


1. Open Biffi Assistant and left-click of the mouse on the “Work Offline” button.

Figure 69




2. Insert the password and left-click of the mouse on “Import file”. To cancel the importation, left-click of the mouse on the left arrow.

Figure 70




3. A “Windows Explorer” window is automatically opened. Browse for finding the file to import. Select the file to import and left click of the mouse on “Open”.

Figure 71



4. Wait until the file is imported.

Figure 72

Now it is possible to analyse Offline the imported data and to modify their value for creating a “new” Biffi Assistant file (see 5.2.2). For Logging Out, left-click of the mouse on “Logout”.


The type of data imported (parameters, graphs and parameters + graph) depends on how the exportation of the file was performed (see 5.2.1 and 5.2.2).

5.1.2.1 Change the Offline Password

For changing the Offline password the following steps must be performed:


1. Import a file Offline (see 5.1.2).
2. Left-click of the mouse on “Change password”.

Figure 73



3. Write the Old password and the new one (twice) then left-click of the mouse on the “Save” button.

Figure 74



For re-establishing the default Offline password, the default settings must be restored (see 3.1).

5.2 Export File

The Biffi Assistant allows exporting the data of device in two ways:


- Online (see 5.2.1)
- Offline (see 5.2.2)

5.2.1 Export File – Online

For exporting a file Online the following steps must be performed:

1. Establish a connection with the device (see 3).
2. Left-click of the mouse on “Export”.

Figure 75




3. Select the Objects to export and left-click of the mouse on the “Export” button. Left-click of the mouse on the “Undo” button to cancel the exportation.

Objects to export:


- All PARAM: if checked, all the parameters of the IMVS2000v2 are exported
- All LOG: it does not affect the exportation of the IMVS2000v2
- All GRAPH: if checked, all the loaded graphs are exported (see Sections 7.1.1 and 7.1.2)
- Export as text file: if checked the file is exported as a text file otherwise as a Biffi Assistant file.

Figure 76




4. A “Windows Explorer” window is automatically opened. Browse for finding the folder to export the file. Write the name of the file and left-click of the mouse on “Save”. The file extension must be “.Biffia” or “.txt”.

Figure 77




5. The exporting procedure starts.

Figure 78



6. A “Windows Explorer” window is automatically opened for verifying that the file is correctly saved. Close the “Windows Explorer” window to continue to work Online.

Figure 79




5.2.2 Export File – Offline

For exporting a file Offline the following steps must be performed:


1. Import a file Offline (see 5.1.2)
2. If it is necessary, modify the value of some parameters.
3. “Write all the parameters” of the device (see 4.3.4). This operation must be performed to correctly export the file.
4. Left-click of the mouse on “Export”.

Figure 80




5. A “Windows Explorer” window is automatically opened. Browse for finding the folder to export the file. Write the name of the file and left-click of the mouse on “Save”. The file extension must be “.Biffia”.

Figure 81



6. A “Windows Explorer” window is automatically opened for verifying that the file is correctly saved. Close the “Windows Explorer” window to continue to work Offline.

Figure 82



For Logging Out, left-click of the mouse on “Logout”.


Section 6: List of Parameters

For details about all the parameters excepting the ones of the “Graphs Menu”, see [1].
 For details about the parameters of the “Graphs Menu”, see Section 7.

6.1 View Graph of the Biffi Assistant Menu

For making easier the reading of the View Graph, a different color is associated to the different entries of the menus.

- Menu and Sub-Menu
- Exit of Menu and Sub-Menu
- Available Parameter
- Available Command/Calibration
- Available Command/Parameter for VAC only (for Biffi use only)
- Unavailable Command/Parameter (for Biffi use only)



HW Settings	..Exit Device Data
	Act. Mode
	Open. Rot.
	Fail Action
	SOVs Qty
	Pr. S. 1-2
	Proc. S.
	Set Pr. 1-2
	Set Proc.
	RL A Cmd.
	RL B Cmd.
FST Settings	..Exit FST Settings
	Sign. En.
	Op. Pos. %
	Cl. Pos. %
	Op. Time %
	Cl. Time %
	FST Pr. %
	H. Pr. Lim.
	L. Pr. Lim.
	H. Proc. L.
	L. Proc. L.
	FST Cyc. L.
	FST Cyc. C.
	FST Ab. C.
PST Settings	..Exit PST Settings
	PST En.
	PST Set.
	PST Pos. %
	PST Pr. %
	PST Time %
	PST Ser. SOVs
	PST Cyc. L.
	PST Cyc. C.
	PST Ab. C.
	A. PST En.
	A. PST Per.
	A. PST Date
	A. PST Time

Calibration	..Exit Calibration	
	Calibration Cmd	
	Cal. Date	
	Cal. Time	
	Cal. Status	
	Cal. Enabled	
FST Settings	..Exit Signatures-FST	
	Base. Sig. Cmd	
	Mnt. Sig. Cmd	
	Op. Cal. T.	
	Op. Max. T.	
	Cl. Cal. T.	
	Cl. Max. T.	
	Base. S. St.	
	B.S. Date	
	B.S. Time	
	Op. Status	
	Cl. Status	
	Mnt S. St.	
	M.S. Date	
	M.S. Time	
	FST Stored	
	FST ID	
	FST Info	
	FST Run Times	..Exit FST Run Times
		B. Op. B. T.
	M. Op. B. T.	
	B. Op. T. T.	
	M. Op. T. T.	
	B. Op. B. P.	
	M. Op. B. P.	
	B. Cl. B. T.	
	M. Cl. B. T.	
	B. Cl. T. T.	
	M. Cl. T. T.	
	B. Cl. B. P.	
	M. Cl. B. P.	

PST Results	..Exit PST Results		
	Base. PST Cmd		
	Manual PST Cmd		
	PST Set.		
	PST Cal. T.		
	PST Max. T.		
	B. PST St.		
	B. PST Date		
	B. PST Time		
	PST St.		
	M. PST Date		
	M. PST Time		
	PST Stored		
	PST ID		
	PST Info		
	PST Run Times		..Exit PST Run Times
			B. PST B. T.
			M. PST B. T.
			B. PST T. T.
			M. PST T. T.
		B. PST B. P.	
		M. PST B. P.	
Date and Time		..Exit Date and Time	
		Date	
		Time	
		N.M. Date	

Alarms	..Exit Alarms	
	CFA. St.	
	Alarms Status	
	Alarms List	
	Clear Alarms List	
	Reset Alarms	
	Alarms Enabled	..Exit Alarms Enabled
		Al. PSCL En.
		Al. PSCT En.
		Al. PSSB En.
		Al. PSFB En.
		Al. PSST En.
		Al. PSFT En.
		Al. PSSP En.
	Al. PSSR En.	
	Al. PSLB En.	
	Al. PSHB En.	
	Al. PSNM En.	
	Al. PSA En.	
	Al. PSB En.	
	Al. SISA En.	
	Al. SISB En.	
	Al. OPOS En.	
	Al. CPOS En.	
	Al. LSP En.	
	Al. HSP En.	
	Al. LPP En.	
	Al. HPP En.	
	Al. OPNM En.	
	Al. CLNM En.	
	Al. OPCT En.	
	Al. CLCT En.	
	Al. FSCL En.	
	Al. SOBT En.	
	Al. FOBT En.	
	Al. SOTT En.	
	Al. FOTT En.	
	Al. SCBT En.	
	Al. FCBT En.	
	Al. SCTT En.	
	Al. FCTT En.	
	Al. OHBP En.	
	Al. OLBP En.	
	Al. CHBP En.	
	Al. CLBP En.	
	Al. PS1 En.	
	Al. PS2 En.	
	Al. PPS En.	
	Al. POS En.	
	Al. BUS En.	
	Al. MNT En.	

Options	..Exit Options RS232 Baud Pres. M.U. CFA Mode Op. Cl. Mode Bus Type Blue. En. Change User PWD M.FST Al. En.										
Sensors Calibration											
Bus (*)											
Factory Settings	..Exit Factory Settings Pressure Calib. Memory Check AO Calibration Digital Inputs										
	<table border="1"> <tr> <td style="background-color: #92d050;">..Exit Digital Inputs</td> <td>DI_SOVA St.</td> </tr> <tr> <td></td> <td>DI_SOVB St.</td> </tr> <tr> <td></td> <td>DI_PST St.</td> </tr> <tr> <td></td> <td>DI_SIS_A St.</td> </tr> <tr> <td></td> <td>DI_SIS_B St.</td> </tr> </table>	..Exit Digital Inputs	DI_SOVA St.		DI_SOVB St.		DI_PST St.		DI_SIS_A St.		DI_SIS_B St.
..Exit Digital Inputs	DI_SOVA St.										
	DI_SOVB St.										
	DI_PST St.										
	DI_SIS_A St.										
	DI_SIS_B St.										
	Check DOs Restore Defaults										
Stored Graphs	..Exit Stored Graphs Graph Type Graph ID Slot Address Store Graph Clear Slots Graph Info										

(*): Menu available only if a bus card is present.
 See the manual dedicated to the specific bus card for details.

Section 7: Graphs

The following paragraph explains how to visualize the FST and PST graphs.

The FST Graphs have the following path: **FST Signatures > FST Signatures > FST Graphs**

The PST Graphs have the following path: **PST Results > PST Results > PST Graphs**

Stored PST and/or FST graphs have the following path: **Stored Graphs > Stored Graphs > Graphs Info**

The “Graph” parameter is organized in three “Views”:

- General View
- Grid View
- Chart View

7.1 General View – Graphs

The General View of the “PST graphs” has the additional field “SOVs” that indicates which SOVs are used during the PST.

7.1.1 General View – FST Graphs

Use the scroll bar for viewing all the loaded graphs.

Figure 83

The screenshot shows the Biffi Assistant software interface. The main window displays the 'FST Graphs' section. The 'Objects' table lists several items, with '1022 FST Graphs' selected. Below this, the 'General View' is active, showing a table of FST Graphs with columns for ID, Type, Source, Status, Date, Time, Break Pressure, Break Time, and Travel Time. The status bar at the bottom indicates 'Connected at 115200 bps (Bluetooth)'.


ID	Name	Value	UM	Min	Max	Flags
1011	Mrt S. St.	Passed		0	4	R
1012	M.S. Date	23/02/2015		2014.01.01	2099.12.31	R
1013	M.S. Time	04:25		00:00	23:59	R
1014	FST Stored	6		0	50	R
1022	FST Graphs	*	*	*	*	R

ID	Type	Source	Status	Date	Time	Break Pressure	Break Time	Travel Time
1	FST OP	Baseline	Passed	23/02/2015	04:24:29	11.0 bar	0.57 sec	3.73 sec
2	FST CL	Baseline	Passed	23/02/2015	04:24:14	15.0 bar	1.08 sec	1.66 sec
3	FST OP	Digital Input	Passed	25/02/2015	22:39:00	11.1 bar	0.57 sec	3.73 sec
4	FST CL	Digital Input	Passed	25/02/2015	22:38:56	14.8 bar	1.06 sec	1.65 sec
5	FST OP	Maintenance	Passed	23/02/2015	04:25:31	11.1 bar	0.57 sec	3.73 sec
6	FST CL	Maintenance	Passed	23/02/2015	04:25:16	14.8 bar	1.09 sec	1.65 sec

7.1.2 General View – PST Graphs

Use the scroll bar for viewing all the loaded graphs.

Figure 84




7.2 Grid View – Graphs

The Grid View allows displaying all the stored values (pressure and optionally position) of a single graph. See [1] for details.

For adding a graph, left-click of the mouse on the button corresponding to the Graph ID of the graph that has to be loaded (2 in the screen below).



Use the scroll bar for viewing all the loaded graphs.

Figure 85



Wait until the graph is loaded.

Figure 86




On the "ID" column, there is the progressive number of the samples of the graph.
On the "TIME" column, the time is reported in seconds.
On the "PRESSURE 1" column, the pressure of the pressure sensor 1 is reported in bar/psi.
On the "PRESSURE 2" column, the pressure of the pressure sensor 2 (optional) is reported in bar/psi.

On the “PROCESS PRESSURE” column, the pressure of the process pressure sensor (optional) is reported in bar/psi.
On the “P1-P2” column, the differential pressure of the pressure sensors 1 and 2 (optional) is reported in bar/psi.
On the “POSITION” column, the position is reported in %.
The three first lines of the Tab resumes the general data relevant to the limit values of pressures and position (see [1]).
Each row reports the time and the value of on sample of pressure and position.
The data not sampled (sensors not present) are shown as “*”.
See [1] for additional details about the graphs.



It is possible to load up to two graphs per time (1 and 2 in the screen below) and to view one graph per time.

Figure 87





Left click of the mouse on the desired Graph ID for viewing the corresponding graph.

Figure 88



For removing a loaded graph, left click of the mouse on the button corresponding to the Graph ID of the graph that has to be removed (4 in the screen below).


Figure 89



7.3 Chart View



For adding a graph, left-click of the mouse on the button corresponding to the Graph ID of the graph that has to be loaded (3 in the screen below)

Figure 90



Wait until the graph is loaded.



Figure 91



The Reverse X Axis and X axis bar is present starting from Biffi Assistant 1.03.00.00 or further versions.

Left click of the mouse on the available samples (in the picture below are available PRESSURE 1 and POSITION) to view them as graph.

Figure 92




Left click of the mouse on “Track Points” to view the details of each single sample of the graph.

Figure 93





It is possible to load up to two graphs per time (1 and 3 in the screen below) and viewing the pressure and position graphs of the loaded graphs.

Figure 94



For removing a loaded graph, left click of the mouse on the button corresponding to the Graph ID of the graph that has to be removed (2 in the screen below).


Figure 95



7.3.1 Chart View – Full Screen


Right click of the mouse on the opening graph and left click of the mouse on “Full Screen” for viewing the graph on the full screen.

Figure 96



A window dedicated to the graph is opened and it is possible to apply all the options of the “Chart View” (see 7.3).

Figure 97




It is possible to minimize, maximize or close the window dedicated to the graph by using the buttons on right the corner on the top.

7.3.2 Chart View – Export Graph


Right click of the mouse on the opening graph and left click of the mouse on “Export” for exporting the graph into an image file (.png).

Figure 98



Select the File Name and the folder and then left click of the mouse on Save.



Figure 99



7.3.3 Chart View – Select X Axis and Reverse X Axis


It is possible to select the X axis. The default is Time (sec). In the picture below, PRESSURE 1 and POSITION are available and POSITION is selected.

Figure 100




Through the scroll bar it is possible “to stretch” the graph.

Figure 101



Select “Reverse X Axis” for inverting the scale of the X axis.


Figure 102



7.4 Stored Graphs

Through the “Stored Graphs” Menu it is possible to permanently memorize up to 20 FST and/or PST graphs.

Figure 97



Graph Type: it indicates the type of graph to store (FST or PST).

Graph ID: it indicates the ID of the graph to store (from 1 to 50). The ID must correspond to an existing graph.

Slot Address: it indicates the slot where to store the graph (from 1 to 20).

Store Graph: it is the command for storing the graph, selected through “Graph Type” and “Graph ID” into the slot = “Slot Address”.

Clear Slots: it is the command to clear the whole memory (all the 20 slots).

Graph Info: it contains the data of the stored graphs (see 7 for details).



EXAMPLE OF GRAPH STORAGE

Select “Graph Type” and “Graph ID” (FST and 2 in the example).

Select “Slot Address” (4 in the example).

Launch the “Store Graph” command.

Figure 104



Appendix A: RS232 Cable

Biffi P/N: 480CABPROG
Maximum cable length: 10 meters

Table A-1

9 PIN D-SUB	90156-0143	PIN FUNCTION
Pin 1		
Pin 2	Pin 2	RX
Pin 3	Pin 3	TX
Pin 4		
Pin 5	Pin 1	GROUND - SHIELD
Pin 6		
Pin 7		
Pin 8		
Pin 9		

Figure A-1 9 PIN D-SUB





Figure A-2 90156-0143



Appendix B: Approved Bluetooth Adapters List

In this appendix is reported a list of the approved Bluetooth adapters for the Biffi Assistant software.

These adapters must use the Windows Bluetooth software and drivers (stack) included with Windows XP Professional Service Pack 2 or 3 or Windows 7 Enterprise. No driver installation is required. Here below is the list of USB/Bluetooth adapters working with Windows Bluetooth software.

Table B-1

USB/Bluetooth adapter	Windows XP	Windows 7
HAMLET EXAGERATE XBTUS100 2.0 cl. 1	ok	ok
BELKIN F8T017 Bluetooth Adapter cl. 1	no*	ok
SITECOM CN-523 USB microadapter Bluetooth 2.1 version 100 m	ok	ok
ATLANTIS Mobile Life mini Bluetooth 2.1 30 metri, PO08-BT-038	ok	ok
KENSINGTON Bluetooth 2.1 USB Micro Adapter PN/MN:K33902 / M01011	ok	ok
DIGICOM PALLADIO USB Bluetooth EDR 100	no*	ok
TARGUS Mod.ACB10-US	no*	ok

If you have other third-party Bluetooth adapter, the required Windows drivers may not be used by the adapter and it may not be able to communicate with the Biffi Assistant. In this case it needs to install the appropriate driver supplied with the Bluetooth adapter. Refer to installation manual of driver for detailed instruction. Administrator account is required to install a new driver.

* The Bluetooth adapters indicated with “no” can work only after installing the appropriate driver

Appendix C: Biffi Assistant PC Requirements

The Biffi Assistant is tested for working with the following OS:

- Windows XP - 32bit service pack 2 or 3 and .NET Framework >= 4.0
- Windows 7 - 32bit
- Windows 7 - 64bit

Appendix D: Biffi Assistant Install/Uninstall

⚠ WARNING

Installation can be done only by the administrator of PC.

NOTICE

“Biffi-Assistant” for PC installation software consists of two files:

- BiffiAssistant.msi
- setup.exe


D.1 Install Biffi Assistant

Before initiating the installation procedure of a new version of Biffi-Assistant remove any previously installed version.

The installation process starts by a double click of the left key of mouse on “setup.exe”.


A simple wizard will guide through the installation process:

Figure D-1



Click Next and then agree to End User License Agreement. Select installation folder and then click Next.

Figure D-2



Left click of mouse on “Next” to begin the program installation.

When the message “Installation complete” appears left click on Close.


An icon with Biffi logo, named **Biffi-Assistant** will be created on the desktop and a new program folder, named “Biffi”, will be added to Start Menu\Program folder.

The program starts by a double left click of mouse.

D.2 Uninstall Biffi Assistant

In the taskbar, click “Start”. Left click of mouse on “Control Panel” and then double left click on “Programs and Features”. Left click on Biffi Assistant.

Figure D-3



Right click of mouse on Biffi Assistant. Left click on “Uninstall” and then “YES”. Biffi Assistant will be removed and PC is ready to re-install a new version.

Biffi Italia s.r.l.
Strada Biffi 165
29017 Fiorenzuola d'Arda (PC)
Italy
T +39 0523 944 411

For complete list of sales and manufacturing sites, please visit
www.Biffi.it or contact us at Biffi_italia@Biffi.it

VCIOM-15743-EN ©2021 Biffi. All rights reserved.

The contents of this publication are presented for information purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the designs or specifications of our products at any time without notice.

